

FOREWORD

This manual contains an introductory description on the SUZUKI LT-A750X/P and procedures for its inspection/ service and overhaul of its main components.

Other information considered as generally known is not included.

Read the GENERAL INFORMATION section to familiarize yourself with the vehicle and its maintenance. Use this section as well as other sections to use as a guide for proper inspection and service.

This manual will help you know the vehicle better so that you can assure your customers of fast and reliable service.

** This manual has been prepared on the basis of the latest specifications at the time of publication. If modifications have been made since then, differences may exist between the content of this manual and the actual vehicle.*

** Illustrations in this manual are used to show the basic principles of operation and work procedures. They may not represent the actual vehicle exactly in detail.*

** This manual is written for persons who have enough knowledge, skills and tools, including special tools, for servicing SUZUKI vehicles. If you do not have the proper knowledge and tools, ask your authorized SUZUKI motorcycle dealer to help you.*

⚠ WARNING

Inexperienced mechanics or mechanics without the proper tools and equipment may not be able to properly perform the services described in this manual.

Improper repair may result in injury to the mechanic and may render the vehicle unsafe for the rider and passenger.

SUZUKI MOTOR CORPORATION

TABLE OF CONTENTS

Precautions.....	00-i	Body and Accessories.....	9-i
Precautions	00-1	Precautions	9-1
General Information	0-i	Wiring Systems	9A-1
General Information	0A-1	Lighting Systems	9B-1
Maintenance and Lubrication	0B-1	Combination Meter / Fuel Meter / Horn	9C-1
Service Data.....	0C-1	Exterior Parts	9D-1
Engine	1-i	Body Structure	9E-1
Precautions	1-1		
Engine General Information and Diagnosis	1A-1		
Emission Control Devices	1B-1		
Engine Electrical Devices.....	1C-1		
Engine Mechanical.....	1D-1		
Engine Lubrication System	1E-1		
Engine Cooling System.....	1F-1		
Fuel System	1G-1		
Ignition System.....	1H-1		
Starting System.....	1I-1		
Charging System.....	1J-1		
Exhaust System	1K-1		
Suspension.....	2-i		
Precautions	2-1		
Suspension General Diagnosis.....	2A-1		
Front Suspension	2B-1		
Rear Suspension.....	2C-1		
Wheels and Tires	2D-1		
Driveline / Axle	3-i		
Precautions	3-1		
Drive Chain / Drive Train / Drive Shaft.....	3A-1		
Differential.....	3B-1		
Transfer.....	3C-1		
Propeller Shafts.....	3D-1		
Brake	4-i		
Precautions	4-1		
Brake Control System and Diagnosis	4A-1		
Front Brakes.....	4B-1		
Rear Brakes	4C-1		
Parking Brake.....	4D-1		
Transmission / Transaxle	5-i		
Precautions	5-1		
Automatic Transmission.....	5A-1		
Steering.....	6-i		
Precautions	6-1		
Steering General Diagnosis	6A-1		
Steering / Handlebar	6B-1		

00

0

1

2

3

4

5

6

9

SUPPLEMENTS

LT-A750XK9 ('09 MODEL)

10

LT-A750XPK9 ('09 MODEL)

11

Section 00



Precautions

CONTENTS

Precautions	00-1	General Precautions	00-1
Precautions.....	00-1	Precautions for Electrical Circuit Service	00-2
Warning / Caution / Note.....	00-1		

Precautions

Precautions

Warning / Caution / Note

B831G20000001

Please read this manual and follow its instructions carefully. To emphasize special information, the symbol and the words WARNING, CAUTION and NOTE have special meanings. Pay special attention to the messages highlighted by these signal words.

⚠ WARNING

Indicates a potential hazard that could result in death or injury.

⚠ CAUTION

Indicates a potential hazard that could result in vehicle damage.

NOTE

Indicates special information to make maintenance easier or instructions clearer.

Please note, however, that the warnings and cautions contained in this manual cannot possibly cover all potential hazards relating to the servicing, or lack of servicing, of the vehicle. In addition to the WARNINGS and CAUTIONS stated, you must use good judgement and basic mechanical safety principles. If you are unsure about how to perform a particular service operation, ask a more experienced mechanic for advice.

General Precautions

B831G20000002

⚠ WARNING

- Proper service and repair procedures are important for the safety of the service mechanic and the safety and reliability of the vehicle.
- When 2 or more persons work together, pay attention to the safety of each other.
- When it is necessary to run the engine indoors, make sure that exhaust gas is forced outdoors.
- When working with toxic or flammable materials, make sure that the area you work in is well ventilated and that you follow all of the material manufacturer's instructions.
- Never use gasoline as a cleaning solvent.

- To avoid getting burned, do not touch the engine, engine oil, radiator and exhaust system until they have cooled.
- After servicing the fuel, oil, water, exhaust or brake systems, check all lines and fittings related to the system for leaks.

⚠ CAUTION

- If parts replacement is necessary, replace the parts with Suzuki Genuine Parts or their equivalent.
- When removing parts that are to be reused, keep them arranged in an orderly manner so that they may be reinstalled in the proper order and orientation.
- Be sure to use special tools when instructed.
- Make sure that all parts used in reassembly are clean. Lubricate them when specified.
- Use the specified lubricant, bond, or sealant.
- When removing the battery, disconnect the negative (–) cable first and then the positive (+) cable.
- When reconnecting the battery, connect the positive (+) cable first and then the negative (–) cable, and replace the terminal cover on the positive (+) terminal.
- When performing service to electrical parts, if the service procedures do not require use of battery power, disconnect the negative (–) cable the battery.
- When tightening the cylinder head or case bolts and nuts, tighten the larger sizes first. Always tighten the bolts and nuts diagonally from the inside toward outside and to the specified tightening torque.
- Whenever you remove oil seals, gaskets, packing, O-rings, locking washers, self-locking nuts, cotter pins, circlips and certain other parts as specified, be sure to replace them with new ones. Also, before installing these new parts, be sure to remove any left over material from the mating surfaces.

- **Never reuse a circlip. When installing a new circlip, take care not to expand the end gap larger than required to slip the circlip over the shaft. After installing a circlip, always ensure that it is completely seated in its groove and securely fitted.**
- **Use a torque wrench to tighten fasteners to the specified torque. Wipe off grease and oil if a thread is smeared with them.**
- **After reassembling, check parts for tightness and proper operation.**
- **To protect the environment, do not unlawfully dispose of used motor oil, engine coolant and other fluids: batteries, and tires.**
- **To protect Earth's natural resources, properly dispose of used vehicle and parts.**

Precautions for Electrical Circuit Service


B831G20000003

When handling the electrical parts or servicing the FI systems, observe the following points for the safety of the systems.

Electrical Parts

Connector / Coupler


- When connecting a connector, be sure to push it in until a click is felt.



I310G1000001-01


- With a lock type coupler, be sure to release the lock when disconnecting, and push it in fully to engage the lock when connecting.
- When disconnecting the coupler, be sure to hold the coupler body and do not pull the lead wires.
- Inspect each terminal on the connector/coupler for looseness or bending.
- Push in the coupler straightly. An angled or skewed insertion may cause the terminal to be deformed, possibly resulting in poor electrical contact.
- Inspect each terminal for corrosion and contamination. The terminals must be clean and free of any foreign material which could impede proper terminal contact.

- Before refitting the sealed coupler, make sure its seal rubber is positioned properly. The seal rubber may possibly come off the position during disconnecting work and if the coupler is refitted with the seal rubber improperly positioned, it may result in poor water sealing.




I310G1000002-01

- Inspect each lead wire circuit for poor connection by shaking it by hand lightly. If any abnormal condition is found, repair or replace.



I310G1000003-02

- When taking measurements at electrical connectors using a tester probe, be sure to insert the probe from the wire harness side (backside) of the connector/coupler.




I649G1000013-02

1. Coupler	2. Probe
------------	----------

- When connecting meter probe from the terminal side of the coupler (where connection from harness side not being possible), use extra care not to force and cause the male terminal to bend or the female terminal to open. Connect the probe as shown to avoid opening of female terminal. Never push in the probe where male terminal is supposed to fit.

00-3 Precautions:

- Check the male connector for bend and female connector for excessive opening. Also check the coupler for locking (looseness), corrosion, dust, etc.




I649G1000030-02

3. Coupler	4. Probe	"A": Where male terminal fits
------------	----------	-------------------------------

Clamp


- Clamp the wire harness at such positions as indicated in "Wiring Harness Routing Diagram in Section 9A (Page 9A-4)".
- Bend the clamp properly so that the wire harness is clamped securely.
- In clamping the wire harness, use care not to allow it to hang down.
- Do not use wire or any other substitute for the band type clamp.



I718H1000001-02

Fuse

- When a fuse blows, always investigate the cause to correct it and then replace the fuse.
- Do not use a fuse of different capacity.
- Do not use wire or any other substitute for the fuse.




I649G1000001-02

Switch

Never apply grease material to switch contact points to prevent damage.


ECM / Various sensors

- Since each component is a high-precision part, great care should be taken not to apply any severe impacts during removal and installation.




I310G1000007-01

- Be careful not to touch the electrical terminals of the electronic parts (ECM, etc.). The static electricity from your body may damage these.



I310G1000008-01


- When disconnecting and connecting the coupler, make sure to turn OFF the ignition switch, or electronic parts may get damaged.



I831G1000001-01


Battery

- Battery connection in reverse polarity is strictly prohibited. Such a wrong connection will damage the components of the FI systems instantly when reverse power is applied.




I718H1000004-01

- Removing any battery terminal of a running engine is strictly prohibited. The moment such removal is made, damaging counter electromotive force will be applied to the ECM which may result in serious damage.



I310G1000011-01

- Before measuring voltage at each terminal, check to make sure that battery voltage is 11 V or higher. Terminal voltage check with a low battery voltage will lead to erroneous diagnosis.



I310G1000012-02

- Never connect any tester (voltmeter, ohmmeter, or whatever) to the electronic unit when its coupler is disconnected. Otherwise, damage to electronic unit may result.
- Never connect an ohmmeter to the ECM with its coupler connected. If attempted, damage to ECM or sensors may result.
- Be sure to use a specified voltmeter/ohmmeter. Otherwise, accurate measurements may not be obtained and personal injury may result.

Electrical Circuit Inspection Procedure

While there are various methods for electrical circuit inspection, described here is a general method to check for open and short circuit using an ohmmeter and a voltmeter.


Open circuit check

Possible causes for the open circuit are as follows. As the cause can exist in the connector/coupler or terminal, they need to be checked carefully.

- Loose connection of connector/coupler
- Poor contact of terminal (due to dirt, corrosion or rust, poor contact tension, entry of foreign object etc.)
- Wire harness being open.
- Poor terminal-to-wire connection.

When checking system circuits including an electronic control unit such as ECM, etc., it is important to perform careful check, starting with items which are easier to check.

- Disconnect the negative (–) cable from the battery.
- Check each connector/coupler at both ends of the circuit being checked for loose connection. Also check for condition of the coupler lock if equipped.



I718H1000005-02


1. Sensor	"A": Check for loose connection
-----------	---------------------------------

00-5 Precautions:

- 3) Using a test male terminal, check the female terminals of the circuit being checked for contact tension.

Check each terminal visually for poor contact (possibly caused by dirt, corrosion, rust, entry of foreign object, etc.). At the same time, check to make sure that each terminal is fully inserted in the coupler and locked.

If contact tension is not enough, rectify the contact to increase tension or replace. The terminals must be clean and free of any foreign material which could impede proper terminal contact.




I649G1000027-02

"B": Check contact tension by inserting and removing.

"C": Check each terminal for bend and proper alignment.

- 4) Using continuity inspect or voltage check procedure as described below, inspect the wire harness terminals for open circuit and poor connection. Locate abnormality, if any.



I649G1000028-02

"D": Looseness of crimping


"E": Open

"F": Thin wire (A few strands left)

Continuity check

- 1) Measure resistance across coupler "B" (between "A" and "C" in figure).


If no continuity is indicated (infinity or over limit), the circuit is open between terminals "A" and "C".



I705H1000006-02

- 2) Disconnect the coupler "B" and measure resistance between couplers "A" and "B-1".

If no continuity is indicated, the circuit is open between couplers "A" and "B-1". If continuity is indicated, there is an open circuit between couplers "B-2" and "C" or an abnormality in coupler "B-2" or coupler "C".



I705H1000010-02

Voltage check

If voltage is supplied to the circuit being checked, voltage check can be used as circuit check.

- 1) With all connectors/couplers connected and voltage applied to the circuit being checked, measure voltage between each terminal and body ground.
- 2) If measurements were taken as shown in the figure and results were listed in the following, it means that the circuit is open between terminals "A" and "B".

Voltage between

"A" and body ground: Approx. 5 V

"B" and body ground: Approx. 5 V

"C" and body ground: 0 V



- 3) Also, if measured values are as listed following, a resistance (abnormality) exists which causes the voltage drop in the circuit between terminals "A" and "B".

Voltage between

"A" and body ground: Approx. 5 V

"B" and body ground: Approx. 5 V – 2 V voltage drop

"C" and body ground: 3 V – 2 V voltage drop



I705H1000007-01


Short circuit check (Wire harness to ground)

- 1) Disconnect the negative (–) cable from the battery.
- 2) Disconnect the connectors/couplers at both ends of the circuit to be checked.

NOTE

If the circuit to be checked branches to other parts as shown, disconnect all connectors/couplers of those parts. Otherwise, diagnosis will be misled.


- 3) Measure resistance between terminal at one end of circuit ("A" terminal in figure) and body ground. If continuity is indicated, there is a short circuit to ground between terminals "A" and "C".



I705H1000008-01

"D": To other parts	"E": Other parts
---------------------	------------------

- 4) Disconnect the connector/coupler included in circuit (coupler "B") and measure resistance between terminal "A" and body ground. If continuity is indicated, the circuit is shorted to the ground between terminals "A" and "B".



I705H1000009-02

"D": To other parts


00-7 Precautions:

Using The Multi-Circuit Testers

- Use the Suzuki multi-circuit tester set.
- Use well-charged batteries in the tester.
- Be sure to set the tester to the correct testing range.

Special tool

 (A): 09900-25008 (Multi-circuit tester set)




I649G1000024-03

Using the testers

- Incorrectly connecting the (+) and (−) probes may cause the inside of the tester to be burnout.
- If the voltage and current are not known, make measurements using the highest range.
- When measuring the resistance with the multi-circuit tester (1), ∞ will be shown as 10.00 MΩ and “1” flashes in the display.
- Check that no voltage is applied before making the measurement. If voltage is applied the tester may be damaged.
- After using the tester, turn the power off.

Special tool

 : 09900-25008 (Multi-circuit tester set)



I649G1000002-02

NOTE

- When connecting the multi-circuit tester, use the needle pointed probe to the back side of the lead wire coupler and connect the probes of tester to them.
- Use the needle pointed probe to prevent the rubber of the water proof coupler from damage.
- When using the multi-circuit tester, do not strongly touch the terminal of the ECM coupler with a needle pointed tester probe to prevent the terminal damage or terminal bend.

Special tool

 (A): 09900-25009 (Needle pointed probe set)



I649G1000025-03

Section 0

General Information

CONTENTS

0

General Information	0A-1	Fuel Line Inspection	0B-10
General Description	0A-1	Engine Oil and Filter Replacement	0B-10
Symbols	0A-1	Front Differential Gear Oil Inspection	0B-12
Abbreviations	0A-1	Front Differential Gear Oil Replacement	0B-13
SAE-to-Former SUZUKI Term	0A-2	Final Gear Oil Inspection.....	0B-14
Vehicle Side View	0A-3	Final Gear Oil Replacement.....	0B-14
Vehicle Identification Number	0A-3	Throttle Cable Play Inspection and	
Fuel and Oil Recommendation	0A-3	Adjustment	0B-15
Engine Coolant Recommendation	0A-4	Throttle Body Inspection	0B-15
BREAK-IN Procedures.....	0A-4	Cooling System Inspection.....	0B-15
Country and Area Codes	0A-5	Drive V-belt Inspection and Replacement.....	0B-17
Wire Color Symbols	0A-5	Drive Shaft Boots Inspection.....	0B-17
Warning, Caution and Information Labels		Front Brake System Inspection	0B-17
Location	0A-6	Rear Brake Pedal / Rear Brake (Parking	
Component Location	0A-7	Brake) Lever Inspection and Adjustment	0B-19
Electrical Components Location	0A-7	Rear Brake Friction Plate Wear Limit	
Specifications.....	0A-9	Inspection.....	0B-20
Specifications (LT-A750X/ZK8).....	0A-9	Tire Inspection.....	0B-21
Specifications (LT-A750X/ZK9).....	0A-11	Steering System Inspection	0B-21
Special Tools and Equipment.....	0A-11	Toe Adjustment	0B-22
Special Tool	0A-11	Suspensions Inspection	0B-22
Maintenance and Lubrication	0B-1	Chassis Bolt and Nut Inspection	0B-23
Precautions.....	0B-1	Compression Pressure Check	0B-26
Precautions for Maintenance	0B-1	Oil Pressure Check	0B-26
General Description	0B-1	SDS Check.....	0B-26
Recommended Fluids and Lubricants.....	0B-1	Automatic Clutch Inspection.....	0B-26
Scheduled Maintenance	0B-1	Specifications	0B-27
Periodic Maintenance Schedule Chart.....	0B-1	Tightening Torque Specifications.....	0B-27
Lubrication Points	0B-2	Special Tools and Equipment	0B-27
Repair Instructions	0B-3	Recommended Service Material	0B-27
Air Cleaner Element Inspection and Cleaning	0B-3	Special Tool	0B-27
Exhaust Pipe Bolt and Muffler Bolt Inspection	0B-4	Service Data	0C-1
Valve Clearance Inspection and Adjustment	0B-4	Specifications	0C-1
Spark Plug Replacement	0B-9	Service Data.....	0C-1
Spark Plug Inspection and Cleaning.....	0B-9	Tightening Torque List	0C-7
Spark Arrester Cleaning.....	0B-10		

General Information

General Description

Symbols

B831G20101001

Listed in the table below are the symbols indicating instructions and other information necessary for servicing.
The meaning of each symbol is also included in the table.

Symbol	Definition
	Torque control required. Data beside it indicate specified torque.
	Apply oil. Use engine oil unless otherwise specified.
	Apply molybdenum oil solution. (Mixture of engine oil and SUZUKI MOLY PASTE in a ratio of 1:1).
	Apply SUZUKI SUPER GREASE "A" or equivalent. 99000-25010
	Apply SUZUKI MOLY PASTE or equivalent. 99000-25140
	Apply WATER RESISTANCE GREASE. 99000-25160
	Apply SUZUKI SILICONE GREASE or equivalent. 99000-25100
	Apply SUZUKI BOND "1215" or equivalent. 99000-31110
	Apply SUZUKI BOND "1216B" or equivalent. 99000-31230
	Apply THREAD LOCK SUPER "1303" or equivalent. 99000-32030
	Apply THREAD LOCK SUPER "1322" or equivalent. 99000-32110
	Apply THREAD LOCK SUPER "1360" or equivalent. 99000-32130
	Use engine coolant or equivalent. 99000-99032-11X
	Apply or use brake fluid.
	Use special tool.
	Do not reuse.
	Note on reassembly.

Abbreviations

B831G20101002

A:
ABDC: After Bottom Dead Center
AC: Alternating Current
ACL: Air Cleaner, Air Cleaner Box
API: American Petroleum Institute
ATDC: After Top Dead Center
A/F: Air Fuel Mixture
B:
BBDC: Before Bottom Dead Center
BTDC: Before Top Dead Center
B+: Battery Positive Voltage
C:
CKP Sensor: Crankshaft Position Sensor (CKPS)
CKT: Circuit
CO: Carbon Monoxide
CPU: Central Processing Unit

D:

DC: Direct Current
DIFF-LOCK Relay: Differential Lock Relay
DMC: Dealer Mode Coupler
DOHC: Double Over Head Camshaft
DRL: Daytime Running Light
DTC: Diagnostic Trouble Code
E:
ECM: Engine Control Module Engine Control Unit
 (ECU) (FI Control Unit)
ECT Sensor: Engine Coolant Temperature Sensor
 (ECTS)
 Water Temp. Sensor (WTS)

F:

FI: Fuel Injection, Fuel Injector
FP: Fuel pump
FPR: Fuel Pressure Regulator
FP Relay: Fuel Pump Relay

G:**GEN:** Generator**GND:** Ground**GP Switch:** Gear Position Switch**H:****HC:** Hydrocarbons**I:****IAP Sensor:** Intake Air Pressure Sensor (IAPS)**IAT Sensor:** Intake Air Temperature Sensor (IATS)**IG:** Ignition**ISC Valve:** Idle Speed Control Valve (ISCV)**J:****JASO:** Japanese Automobile Standards Organization**L:****LCD:** Liquid Crystal Display**LED:** Light Emitting Diode (Malfunction Indicator Lamp)**LH:** Left Hand**M:****MAL-CODE:** Malfunction Code (Diagnostic Code)**Max:** Maximum**MIL:** Malfunction Indicator Lamp (LED)**Min:** Minimum**N:****NOx:** Nitrogen Oxides**O:****OHC:** Over Head Camshaft**P:****PCV:** Positive Crankcase Ventilation (Crankcase Breather)**R:****RH:** Right Hand**ROM:** Read Only Memory**S:****SAE:** Society of Automotive Engineers**SDS:** Suzuki Diagnosis System**T:****TO Sensor:** Tip-over Sensor (TOS)**TP Sensor:** Throttle Position Sensor (TPS)**SAE-to-Former SUZUKI Term**

B831G20101003

This list shows SAE (Society of Automotive Engineers) J1930 terms and abbreviations which may be used in this manual in compliance with SAE recommendations, as well as their former SUZUKI names.

Ex. SAE term (Abbreviation): Former SUZUKI term

A:**Air Cleaner (ACL):** Air Cleaner, Air Cleaner Box**B:****Battery Positive Voltage (B+):** Battery Voltage, +B**C:****Crankshaft Position Sensor (CKP Sensor):**

Crankshaft Position Sensor (CKPS), Crank Angle

D:**Data Link Connector (DLC):** Dealer Mode Coupler**Diagnostic Test Mode (DTM):** —**Diagnostic Trouble Code (DTC):** Diagnostic Code, Malfunction Code**E:****Electronic Ignition (EI):** —**Engine Control Module (ECM):** Engine Control Module (ECM), FI Control Unit, Engine Control Unit (ECU)**Engine Coolant Level (ECL):** Coolant Level**Engine Coolant Temperature (ECT):** Coolant Temperature, Engine Coolant Temperature, Water Temperature**Engine Speed (RPM):** Engine Speed (RPM)**F:****Fan Control (FC):** —**Fuel Level Sensor:** Fuel Level Sensor, Fuel Level Gauge**Fuel Pump (FP):** Fuel Pump (FP)**G:****Generator (GEN):** Generator**Ground (GND):** Ground (GND, GRD)**I:****Ignition Control Module (ICM):** —**Intake Air Temperature (IAT):** Intake Air Temperature (IAT), Air Temperature**Idle Speed Control (ISC):** —**Ignition Control (IC):** Electronic Spark Advance (ESA)**M:****Malfunction Indicator Lamp (MIL):** LED Lamp, Malfunction Indicator Lamp (MIL)**Manifold Absolute Pressure (MAP):** Intake Air Pressure (IAP), Intake Vacuum**Mass Air Flow (MAF):** Air Flow**O:****On-Board Diagnostic (OBD):** Self-Diagnosis Function, Diagnostic**P:****Programmable Read Only Memory (PROM):** —**R:****Random Access Memory (RAM):** —**Read Only Memory (ROM):** ROM**T:****Throttle Body (TB):** Throttle Body (TB)**Throttle Body Fuel Injection (TBI):** Throttle Body Fuel Injection (TBI)**Throttle Position Sensor (TP Sensor):** TP Sensor (TPS)**V:****Voltage Regulator (VR):** Voltage Regulator

Vehicle Side View


B831G20101004

NOTE

Difference between illustration and actual vehicle may exist depending on the markets.


SUZUKI LT-A750X (2008-model)

Right Side



I831G1010001-01

Left Side




I831G1010002-01


Vehicle Identification Number

B831G20101005

The frame serial number or V.I.N. (Vehicle Identification Number) "A" is stamped on the left side of the front frame pipe. The engine serial number "B" is located on the right side of the crankcase. These numbers are required especially for registering the machine and ordering spare parts.



I831G1010003-01



I831G1010004-01

Fuel and Oil Recommendation

B831G20101006

Fuel (For USA and Canada)

Use only unleaded gasoline of at least 87 pump octane (R/2 + M/2) or 91 octane or higher rated by the research method.

Gasoline containing MTBE (Methyl Tertiary Butyl Ether), less than 10% ethanol, or less than 5% methanol with appropriate cosolvents and corrosion inhibitor is permissible.

Fuel (For Other Countries)

Gasoline used should be graded 91 octane (Research Method) or higher. Unleaded gasoline is recommended.

Engine Oil (For USA)


Oil quality is a major contributor to your engine's performance and life. Always select good quality engine oil.

Suzuki recommends the use of SUZUKI PERFORMANCE 4 MOTOR OIL or an equivalent engine oil. Use of SF/SG or SH/SJ in API with MA in JASO.

Suzuki recommends the use of SAE 10W-40 engine oil. If SAE 10W-40 engine oil is not available, select and alternative according to the chart.

Engine Oil (For Other Countries)

Oil quality is a major contributor to your engine's performance and life. Always select good quality engine oil. Use of SF/SG or SH/SJ in API with MA in JASO. Suzuki recommends the use of SAE 10W-40 engine oil. If SAE 10W-40 engine oil is not available, select an alternative according to the chart.



I831G1010008-01

Front Differential Gear Oil

Use hypoid gear oil that meets the API service classification GL-5 and is rated SAE #90. Use a hypoid gear oil with a rating of SAE #80 if the vehicle is operated where the ambient temperature is below 0 °C (32 °F).

Rear Drive (Final) Gear Oil

Use mobil fluid 424 or equivalent oil.

Brake Fluid

Specification and classification: DOT 4

▲ WARNING

Since the brake system of this vehicle is filled with a glycol-based brake fluid by the manufacturer, do not use or mix different types of fluid such as silicone-based and petroleum-based fluid for refilling the system, otherwise serious damage will result.

Do not use any brake fluid taken from old or used or unsealed containers.

Never reuse brake fluid left over from a previous servicing, which has been stored for a long period.

Engine Coolant Recommendation

B831G20101007

Engine Coolant

Use an anti-freeze/engine coolant compatible with an aluminum radiator, mixed with distilled water only.

Water for mixing

Use distilled water only. Water other than distilled water can corrode and clog the aluminum radiator.

Anti-freeze / Engine coolant

The engine coolant perform as a corrosion and rust inhibitor as well as anti-freeze. Therefore, the engine coolant should be used at all times even though the atmospheric temperature in your area does not go down to freezing point.

Suzuki recommends the use of SUZUKI COOLANT anti-freeze/engine coolant. If this is not available, use an equivalent which is compatible with an aluminum radiator.

Liquid amount of water / Engine coolant**Solution capacity (total)**

2 450 ml (2.6/2.2 US/lmp qt)

For engine coolant mixture information, refer to "Engine Coolant Description in Section 1F (Page 1F-1)".

▲ CAUTION

Mixing of anti-freeze/engine coolant should be limited to 60%. Mixing beyond it would reduce its efficiency. If the anti-freeze/engine coolant mixing ratio is below 50%, rust inhabiting performance is greatly reduced. Be sure to mix it above 50% even though the atmospheric temperature does not go down to the freezing point.

BREAK-IN Procedures

B831G20101008

During manufacture only the best possible materials are used and all machined parts are finished to a very high standard but it is still necessary to allow the moving parts to "BREAK-IN" before subjecting the engine to maximum stresses. The future performance and reliability of the engine depends on the care and restraint exercised during its early life. The general rules are as follows.

1) Keep to these break-in engine speed limits:

Speed limits

Initial 500 km (300 miles): Less than 1/2 throttle

2) Upon reaching an odometer reading of 500 km (300 miles) you can subject the vehicle to full throttle operation, for short periods of time.

Country and Area Codes

B931G20101009

The following codes stand for the applicable country(-ies) and area(-s).

Model	Code	Country or Area	Effective Frame No.
LT-A750XK8	P-17	Sweden	5SAAR41A 87100001 –
	P-24	Australia	
	P-28	Canada	
	P-33	U.S.A.	
LT-A750XZK8	P-17	Sweden	
	P-24	Australia	
	P-28	Canada	
	P-33	U.S.A.	
LT-A750XK9	P-17	Sweden	5SAAR41A 97100001 –
	P-24	Australia	
	P-28	Canada	
	P-33	U.S.A.	
LT-A750XZK9	P-17	Sweden	
	P-28	Canada	
	P-33	U.S.A.	


Wire Color Symbols

B931G20101010

Symbol	Wire Color	Symbol	Wire Color
B	Black	Br/W	Brown with White tracer
Bl	Blue	G/B	Green with Black tracer
Br	Brown	Gr/R	Gray with Red tracer
Dg	Dark green	Gr/W	Gray with White tracer
G	Green	O/G	Orange with Green tracer
Gr	Gray	O/R	Orange with Red tracer
O	Orange	O/W	Orange with White tracer
P	Pink	O/Y	Orange with Yellow tracer
R	Red	O/B	Orange with Black tracer
W	White	O/Bl	Orange with Blue tracer
Y	Yellow	P/W	Pink with White tracer
B/Bl	Black with Blue tracer	R/B	Red with Black tracer
B/Br	Black with Brown tracer	R/G	Red with Green tracer
B/G	Black with Green tracer	W/B	White with Black tracer
B/Lg	Black with Light green tracer	W/Bl	White with Blue tracer
B/R	Black with Red tracer	W/G	White with Green tracer
B/W	Black with White tracer	W/R	White with Red tracer
B/Y	Black with Yellow tracer	W/Y	White with Yellow tracer
Bl/B	Blue with Black tracer	Y/B	Yellow with Black tracer
Bl/G	Blue with Green tracer	Y/Bl	Yellow with Blue tracer
Bl/W	Blue with White tracer	Y/R	Yellow with Red tracer
Bl/R	Blue with Red tracer	Y/G	Yellow with Green tracer
Bl/Y	Blue with Yellow tracer		

Warning, Caution and Information Labels Location

B931G20101011










I831G1010005-06

1. Certification plate	For P-24, 33	13. Max AMP caution label	For P-17, 28
2. Information label	For P-33	14. Fuel caution label	For P-24
3. Gearshift label	For P-17, 24, 28, 33	15. Front carrier warning label	For P-24, 33
4. Gearshift label	For P-28	16. Front carrier warning label	For P-17, 28
5. Tire air pressure label	For P-17, 24, 28, 33	17. Rear carrier warning label	For P-24, 33
6. Tire air pressure label and warning no-passenger label	For P-28	18. Rear carrier warning label	For P-17, 28
7. General warning & AGE, 16 label	For P-17, 24, 28, 33	19. ICES Canada label	For P-28
8. General warning label	For P-28	20. Compliance label No.2	For P-28
9. Warning no-passenger label	For P-17, 24, 28, 33	21. I.D. plate	For P-17
10. AGE, 16 label	For P-28	22. Cooling fan label	For P-17, 24, 28, 33
11. Manual notice label	For P-33	23. Compliance label	For P-28
12. Max AMP caution label	For P-24, 33	[A]: Left side of frame	

Component Location






Electrical Components Location

B931G20103001



I831G1010006-02

1. Battery	7. 4WD/Diff-lock relay	13. Ignition switch
2. Starter relay/Main fuse	8. Mode selection switch coupler	14. Power source
3. Fuse box	9. Starter motor	15. Ignition coil
4. Neutral relay	10. ECT sensor	16. Rear brake switch
5. Fuel pump relay	11. 4WD/Diff-lock switch	17. Gear position switch
6. ECM	12. Brake lever switch (R)	



18. Cooling fan thermo-switch	24. Parking brake switch	30. High position diode
19. Resister	25. Brake lever switch	31. Low position diode
20. 4WD/Diff-lock actuator diode	26. Regulator/Rectifier	32. Speed sensor
21. Neutral relay diode	27. Parking brake relay	33. CKP sensor
22. Cooling fan	28. Diff-lock relay	34. Generator
23. Handlebar switch	29. Actuator	

Specifications

Specifications (LT-A750X/ZK8)

B931G20107001

NOTE

These specifications are subject to change without notice.

Dimensions and dry mass

Item	Specification	Remark
Overall length	2 115 mm (83.3 in)	P-28, 33
	2 135 mm (84.1 in)	P-17, 24
Overall width	1 210 mm (47.6 in)	P-28, 33
	1 250 mm (49.2 in)	P-17, 24
Overall height	1 245 mm (49.0 in)	
Wheelbase	1 280 mm (50.4 in)	
Ground clearance	270 mm (10.6 in)	
Seat height	880 mm (34.6 in)	
Dry mass	273 kg (601 lbs)	P-28, 33
	275 kg (606 lbs)	P-17, 24
Front track	930 mm (36.6 in)	
Rear track	940 mm (37.0 in)	

Engine

Item	Specification	Remark
Type	4-stroke, liquid-cooled, DOHC	
Number of cylinders	1	
Bore	104.0 mm (4.094 in)	
Stroke	85.0 mm (3.346 in)	
Displacement	722 cm ³ (44.1 cu.in)	
Compression ratio	10.0 : 1	
Fuel system	Fuel injection	
Air cleaner	Non-woven fabric element	
Starter system	Electric and recoil starter	
Lubrication system	Wet sump	
Idle speed	1 300 ± 100 r/min	

Drive train

Item	Specification	Remark
Clutch	Wet shoe, automatic, centrifugal type	
Transmission	Automatic variable ratio (V-belt)	
Transfer	2-speed forward with reverse	
Gearshift pattern	Transmission	Automatic
	Transfer	L-H-N-R (Hand operated)
Primary reduction ratio (Automatic drive)	Variable change (2.763 – 0.78)	
Secondary reduction ratio	2.158 (40/21 x 17/15)	
Final reduction ratio (Front & Rear)	3.600 (36/10)	
Transfer gear ratio	Low	2.562 (41/16)
	High	1.240 (31/25)
	Reverse	1.882 (32/17)
Drive system	Shaft drive	

Chassis

Item	Specification	Remark
Front suspension	Independent, double wishbone, coil spring, oil damped	
Rear suspension	Independent, double wishbone, coil spring, oil damped	
Front wheel travel	180 mm (7.1 in)	
Rear wheel travel	200 mm (7.9 in)	
Caster	1.6°	
Trail	3.4 mm (0.13 in)	
Toe-out	10 mm (0.39 in)	
Camber	0.64°	
Steering angle	46° (right & left)	
Turning radius	3.1 m (10.2 ft)	
Front brake	Disc brake, twin	
Rear brake	Sealed oil-bathed multi-disc	
Front tire size	AT25 x 8-12☆☆, tubeless	
Rear tire size	AT25 x 10-12☆☆, tubeless	

Electrical

Item	Specification	Remark
Ignition type	Electronic ignition (CDI)	
Ignition timing	7° B.T.D.C. at 1 300 r/min	
Spark plug	NGK CR6E or DENSO U20ESR-N	
Battery	12 V 64.8 kC (18 Ah)/10 HR	
Generator	Three-phase A.C. generator	
Main fuse	30 A	
Fuse	10/10/10/10/15/15 A	
Headlight	12 V 35/35 W x 2	
Auxiliary light	12 V 35/35 W	
Brake light/Taillight	12 V 21/5 W	
Revercing light	12 V 21 W	P-17
Speedometer light	LED	
Neutral indicator light	LED	
High beam indicator light	LED	P-17
Coolant temperature/FI indicator light	LED	
Reverse indicator light	LED	
Diff-lock indicator light	LED	

Capacities

Item	Specification	Remark
Fuel tank	17.5 L (4.6/3.8 US/lmp gal)	
Engine oil	Oil change	2 300 ml (2.4/2.0 US/lmp qt)
	With filter change	2 500 ml (2.6/2.2 US/lmp qt)
	Overhaul	3 000 ml (3.2/2.6 US/lmp qt)
Differential gear oil	500 ml (0.5/0.4 US/lmp qt)	
Final gear oil	770 ml (0.7/0.6 US/lmp qt)	
Coolant	2 450 ml (2.6/2.2 US/lmp qt)	

Specifications (LT-A750X/ZK9)

B931G20107002

NOTE

- These specifications are subject to change without notice.
- Any differences between the LT-A750X/ZK8 ('08-model) and LT-A750X/ZK9 ('09-model) in specifications are indicated with an asterisk mark (*).
















Dimensions and curb mass

Item	Specification	Remark
Overall length	2 115 mm (83.3 in)	P-28, 33
	2 135 mm (84.1 in)	P-17, 24
Overall width	1 210 mm (47.6 in)	P-28, 33
	1 250 mm (49.2 in)	P-17, 24
Overall height	1 245 mm (49.0 in)	
Wheelbase	1 280 mm (50.4 in)	
Ground clearance	270 mm (10.6 in)	
Seat height	880 mm (34.6 in)	
* Curb mass	302 kg (666 lbs)	P-28, 33
	304 kg (670 lbs)	P-17, 24
Front track	930 mm (36.6 in)	
Rear track	940 mm (37.0 in)	

Special Tools and Equipment

Special Tool

B931G20108001

				
09900-06107 Snap ring pliers	09900-06108 Snap ring pliers	09900-20101 Vernier calipers (1/15 mm, 150 mm)	09900-20102 Vernier calipers (1/20 mm, 200 mm)	09900-20202 Micrometer (1/100 mm, 25 – 50 mm)
				
09900-20205 Micrometer (0 – 25 mm)	09900-20210 Micrometer (100 – 125 mm)	09900-20530 Cylinder gauge set	09900-20602 Dial gauge (1/1000 mm, 1 mm)	09900-20605 Dial calipers (1/100 mm, 10 – 34 mm)
				
09900-20607 Dial gauge (1/100 mm, 10 mm)	09900-20701 Magnetic stand	09900-20803 Thickness gauge	09900-20805 Tire depth gauge	09900-21304 V-block (100 mm)