



CAT
CATERPILLAR



MANUAL






Illustration 21

g02582816

32. Remove breather assembly (60) .
33. Disconnect clip (63) and hose assembly (69) .
34. Loosen clamps (65) and reposition hose (62) .
35. Remove hose assembly (66) .
36. Disconnect harness assembly (64) and clip (70) .
37. Disconnect hose (67) and hose assembly (68) .




Illustration 22

g02582817

38. Disconnect clip (71), hose (72), and hose (73) .

Tool	Item	Qty	Part No	Description
A	A		198-4240	Digital Pressure Indicator Gp
	A1	1	198-4234	Digital Indicator
	A2	1	198-4237	Pressure Sensor Gp (0 to 3,445 kPa (0 to 500 psi))
	A3	1	198-4236	Adapter Cable As

Reference Refer to Tool Operating Manual, NEHS0818, "Using the 198-4240 Digital Pressure Indicator Group" for more information on using Tooling (A) .

Machine Preparation

1. Move the machine to a smooth horizontal location.
2. Place the steering control lever in the NEUTRAL position.
3. Engage the parking brake.
4. Lower the attachments to the ground.
5. Stop the engine.




Illustration 2

g03395826

(1) Bolts



Illustration 2

g01362229

2. Block the front of the machine and block the rear of the machine. Refer to Illustration 1 and Illustration 2.
3. Raise the cab. Refer to the Operation and Maintenance Manual for your machine.




Illustration 3

g03385008

(1) Brake pressure supply line

4. Disconnect the brake pressure supply line (1) at the top of the hydrostatic pump. Install a plug loosely into the hose for contamination prevention only. Do not tighten this plug as pressure should not be allowed to build up in the brake line. Cap the port fitting.
5. Lower the cab and securely bolt the cab to the frame.
6. Sit in the seat. Fasten the seat belt. Lower the armrest.

2. Operate the engine at HIGH IDLE. Make sure that the steering control lever is in the NEUTRAL position. Disengage the parking brake.
3. Check the pressure at tooling (A or B) . The main relief pressure should be 2625 ± 150 kPa (380 ± 22 psi).
4. If the pressure at tooling (A or B) is within the specified limit, the test is complete. If the pressure at tooling (A or B) is not within the specified limit, perform the procedure in "Adjustment Procedure for the Main Relief Valve".

Adjustment Procedure for the Main Relief Valve

1. Perform the steps in "Test Procedure (Transmission Main Relief Valve)".




Illustration 4

g02494836

(1) Bolts

(2) Back Cover

2. Remove bolts (1) from back cover (2) . Remove back cover (2) .

The remote pressure taps and diagnostic ports are located behind the access panel on the left side of the machine.




Illustration 2

g02498337

View of the left side of the cab

Note: The following pressure taps are color coded for assembly purposes only.



Torque converter inlet pressure (R1)
- Brown



Torque converter outlet pressure (R2) - Red



Brake pressure (R3) - Yellow




Illustration 1

g01871219

3. Remove bolts (1) and alternator (2).

Installation Procedure

1. Install alternator (2) in reverse order of removal.




Illustration 2

g01872415

- a. Tighten nut (3) to a torque of 127 ± 10 N·m (94 ± 8 lb ft).
- b. Tighten nut (4) to a torque of 18 ± 2 N·m (161 ± 21 lb in).
- c. Tighten bolt (5) to a torque of 5 ± 1 N·m (39 ± 9 lb in).




Illustration 2

g02559176

(2) Torque converter output speed sensor




Illustration 3


g02559177

(3) Transmission output speed sensor

1. Remove torque converter output speed sensor (2).
2. Align one gear tooth with the speed sensor that is being set.

Location of lift cylinders (1) for a SU Blade

Tilt Cylinder



Location of tilt cylinder (2)



Location of tilt cylinder (2) for a SU Blade

Angle Cylinders




Illustration 2

g03672920

3. Install connecting rod caps (1) and crankshaft main bearing caps (2).
4. Tighten the bolts for connecting rod caps (1) by using the following procedure:
 - a. Tighten each bolt to a torque of 50 ± 5 N·m (37 ± 3 lb ft).
 - b. Place an index mark on each bolt. Tighten each bolt for an additional 90 ± 5 degrees ($1/4$ turn).
5. Tighten the bolts for crankshaft main bearing caps (2) by using the following procedure:
 - a. Tighten each bolt to a torque of 95 ± 5 N·m (70 ± 4 lb ft).
 - b. Place an index mark on each bolt. Tighten each bolt for an additional 90 ± 5 degrees ($1/4$ turn).
6. Install piston cooling jet (3).

End By:

- a. Install the engine oil pump. Refer to Disassembly and Assembly, "Engine Oil Pump - Install".




Illustration 8

g01457661









Illustration 9

g01456446

Note: Failure to adjust lash properly could result in engine damage.

13. On cylinders two, four, and six, set the lash on the compression brake. Position the number six piston to the top center position of compression stroke.
14. Thread adjuster (7) clockwise until the brake piston (8) touches valve bridge (9) .
15. Turn adjuster (7) counterclockwise until the adjuster has turned one full rotation.
16. Use Tooling (A) in order to verify the brake lash of 0.9 ± 0.2 mm (0.035 ± 0.008 inch). The brake lash is measured between brake piston (8) and valve bridge (9) .
17. Tighten locknuts (6) to a torque of 50 ± 10 N·m (37 ± 7 lb ft). Do not allow adjuster (7) to turn while you are tightening locknut (6). Recheck the valve lash after tightening the locknut.





Component Location	Wiring Location
1. Cab	1. Cab
2. Cab	2. Cab
3. Cab	3. Cab
4. Cab	4. Cab
5. Cab	5. Cab
6. Cab	6. Cab
7. Cab	7. Cab
8. Cab	8. Cab
9. Cab	9. Cab
10. Cab	10. Cab
11. Cab	11. Cab
12. Cab	12. Cab
13. Cab	13. Cab
14. Cab	14. Cab
15. Cab	15. Cab
16. Cab	16. Cab
17. Cab	17. Cab
18. Cab	18. Cab
19. Cab	19. Cab
20. Cab	20. Cab
21. Cab	21. Cab
22. Cab	22. Cab
23. Cab	23. Cab
24. Cab	24. Cab
25. Cab	25. Cab
26. Cab	26. Cab
27. Cab	27. Cab
28. Cab	28. Cab
29. Cab	29. Cab
30. Cab	30. Cab
31. Cab	31. Cab
32. Cab	32. Cab
33. Cab	33. Cab
34. Cab	34. Cab
35. Cab	35. Cab
36. Cab	36. Cab
37. Cab	37. Cab
38. Cab	38. Cab
39. Cab	39. Cab
40. Cab	40. Cab
41. Cab	41. Cab
42. Cab	42. Cab
43. Cab	43. Cab
44. Cab	44. Cab
45. Cab	45. Cab
46. Cab	46. Cab
47. Cab	47. Cab
48. Cab	48. Cab
49. Cab	49. Cab
50. Cab	50. Cab

Component Location	Wiring Location
1. Cab	1. Cab
2. Cab	2. Cab
3. Cab	3. Cab
4. Cab	4. Cab
5. Cab	5. Cab
6. Cab	6. Cab
7. Cab	7. Cab
8. Cab	8. Cab
9. Cab	9. Cab
10. Cab	10. Cab
11. Cab	11. Cab
12. Cab	12. Cab
13. Cab	13. Cab
14. Cab	14. Cab
15. Cab	15. Cab
16. Cab	16. Cab
17. Cab	17. Cab
18. Cab	18. Cab
19. Cab	19. Cab
20. Cab	20. Cab
21. Cab	21. Cab
22. Cab	22. Cab
23. Cab	23. Cab
24. Cab	24. Cab
25. Cab	25. Cab
26. Cab	26. Cab
27. Cab	27. Cab
28. Cab	28. Cab
29. Cab	29. Cab
30. Cab	30. Cab
31. Cab	31. Cab
32. Cab	32. Cab
33. Cab	33. Cab
34. Cab	34. Cab
35. Cab	35. Cab
36. Cab	36. Cab
37. Cab	37. Cab
38. Cab	38. Cab
39. Cab	39. Cab
40. Cab	40. Cab
41. Cab	41. Cab
42. Cab	42. Cab
43. Cab	43. Cab
44. Cab	44. Cab
45. Cab	45. Cab
46. Cab	46. Cab
47. Cab	47. Cab
48. Cab	48. Cab
49. Cab	49. Cab
50. Cab	50. Cab