

# **Komatsu PC138-8 Sample File.**

**This single sample file  
contains samples for**

**10533 Komatsu PC138-8 operations and maintenance - 375  
pages**

**10533 Komatsu PC138-8 workshop manual - 946 pages**

# Operation & Maintenance Manual

HYDRAULIC  
EXCAVATOR

**GALEO**

**PC138US -8**

**PC138USLC-8**

SERIAL NUMBERS PC138US- 2001 and up  
PC138USLC-2001

**ecot3**

## NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

## WARNING

Unsafe Use of this machine may cause serious injury or Death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

**KOMATSU**


# CONTENTS

FOREWORD .....	1- 1
FOREWORD .....	1- 2
SAFETY INFORMATION .....	1- 5
INTRODUCTION .....	1- 7
DIRECTIONS OF MACHINE .....	1- 7
BREAKING-IN THE NEW MACHINE .....	1- 7
PRODUCT INFORMATION .....	1- 8
PRODUCT IDENTIFICATION NUMBER (PIN)/MACHINE SERIAL NO. PLATE .....	1- 8
EPA REGULATIONS, ENGINE NUMBER PLATE .....	1- 8
SERVICE METER LOCATION .....	1- 9
YOUR MACHINE SERIAL NUMBERS AND DISTRIBUTOR .....	1- 9
SAFETY .....	2- 1
SAFETY .....	2- 2
SAFETY LABELS .....	2- 4
LOCATION OF SAFETY LABELS .....	2- 5
SAFETY LABELS .....	2- 6
GENERAL PRECAUTIONS .....	2- 13
SAFETY MACHINE OPERATION .....	2- 22
STARTING ENGINE .....	2- 22
OPERATION .....	2- 24
TRANSPORTATION .....	2- 30
BATTERY .....	2- 31
TOWING .....	2- 33
LIFTING OBJECTS WITH BUCKET .....	2- 34
SAFETY MAINTENANCE INFORMATION .....	2- 35
OPERATION .....	3- 1
MACHINE VIEW ILLUSTRATIONS .....	3- 2
OVERALL MACHINE VIEW .....	3- 2
CONTROLS AND GAUGES .....	3- 3
DETAILED CONTROLS AND GAUGES .....	3- 5
MONITORING SYSTEM .....	3- 5
SWITCHES .....	3- 68
CONTROL LEVERS AND PEDALS .....	3- 73
SUN ROOF .....	3- 77
WINDSHIELD .....	3- 77
SLIDING DOOR .....	3- 83
EMERGENCY ESCAPE HAMMER .....	3- 84
CAP WITH LOCK .....	3- 85
ENGINE HOOD .....	3- 86
CAB REAR COVER .....	3- 87
PUMP ROOM DOOR, BATTERY ROOM DOOR .....	3- 88
DOOR AT FRONT OF TOOL BOX .....	3- 89
AIR CONDITIONER CONTROLS .....	3- 90
RADIO .....	3-103
FUSE .....	3-108
FUSIBLE LINK .....	3-109
AUXILIARY ELECTRIC POWER .....	3-110
CONTROLLERS .....	3-111
OPERATION MANUAL STORAGE .....	3-112

TOOL BOX .....	3-112
GREASE PUMP HOLDER .....	3-112
CUP HOLDER .....	3-112
ASHTRAY .....	3-113
FIRE EXTINGUISHER .....	3-113
MACHINE OPERATIONS AND CONTROLS .....	3-114
BEFORE STARTING ENGINE .....	3-114
STARTING ENGINE .....	3-133
AFTER STARTING ENGINE .....	3-138
STOPPING THE ENGINE .....	3-149
MACHINE OPERATION .....	3-150
STEERING THE MACHINE .....	3-154
SWINGING .....	3-156
WORK EQUIPMENT CONTROLS AND OPERATIONS .....	3-157
WORKING MODE .....	3-159
PROHIBITED OPERATIONS .....	3-160
GENERAL OPERATION INFORMATION .....	3-162
TRAVELING ON SLOPES .....	3-165
ESCAPE FROM MUD .....	3-167
RECOMMENDED APPLICATIONS .....	3-168
BUCKET REPLACEMENT AND INVERSION .....	3-170
PARKING MACHINE .....	3-173
MACHINE INSPECTION AFTER DAILY WORK .....	3-174
LOCKING .....	3-175
ROAD LINERS .....	3-176
TRANSPORTATION .....	3-178
TRANSPORTATION PROCEDURE .....	3-178
LOADING AND UNLOADING WITH TRAILER .....	3-179
LIFTING MACHINE .....	3-186
COLD WEATHER OPERATION .....	3-188
COLD WEATHER OPERATION INFORMATION .....	3-188
AFTER DAILY WORK COMPLETION .....	3-189
AFTER COLD WEATHER SEASON .....	3-190
LONG TERM STORAGE .....	3-191
BEFORE STORAGE .....	3-191
DURING STORAGE .....	3-192
AFTER STORAGE .....	3-192
STARTING MACHINE AFTER LONG-TERM STORAGE .....	3-192
TROUBLES AND ACTIONS .....	3-193
RUNNING OUT OF FUEL .....	3-193
PHENOMENA THAT ARE NOT FAILURES .....	3-193
TOWING THE MACHINE .....	3-194
LIGHTWEIGHT TOWING HOOK .....	3-195
SEVERE JOB CONDITION .....	3-195
DISCHARGED BATTERY .....	3-196
OTHER TROUBLE .....	3-201
MAINTENANCE .....	4- 1
MAINTENANCE INFORMATION .....	4- 2
OUTLINE OF SERVICE .....	4- 4
HANDLING OIL, FUEL, COOLANT, AND PERFORMING OIL CLINIC .....	4- 4

ELECTRIC SYSTEM MAINTENANCE -----	4- 7
WEAR PARTS -----	4- 8
WEAR PARTS LIST -----	4- 8
RECOMMENDED FUEL, COOLANT, AND LUBRICANT -----	4- 9
USE OF FUEL, COOLANT AND LUBRICANTS ACCORDING TO AMBIENT TEMPERATURE ----	4- 10
RECOMMENDED BRANDS, RECOMMENDED QUALITY FOR PRODUCTS OTHER THAN KOMATSU GENUINE OIL -----	4- 11
TIGHTENING TORQUE SPECIFICATIONS -----	4- 12
TIGHTENING TORQUE LIST -----	4- 12
SAFETY CRITICAL PARTS -----	4- 13
SAFETY CRITICAL PARTS LIST -----	4- 13
MAINTENANCE SCHEDULE -----	4- 14
MAINTENANCE SCHEDULE CHART -----	4- 14
MAINTENANCE INTERVAL FOR HYDRAULIC BREAKER -----	4- 16
MAINTENANCE PROCEDURE -----	4- 17
WHEN REQUIRED -----	4- 17
CHECK BEFORE STARTING -----	4- 46
EVERY 100 HOURS MAINTENANCE -----	4- 47
EVERY 250 HOURS MAINTENANCE -----	4- 49
EVERY 500 HOURS MAINTENANCE -----	4- 56
EVERY 1000 HOURS MAINTENANCE -----	4- 65
EVERY 2000 HOURS MAINTENANCE -----	4- 71
EVERY 4000 HOURS MAINTENANCE -----	4- 75
EVERY 5000 HOURS MAINTENANCE -----	4- 77
EVERY 8000 HOURS MAINTENANCE -----	4- 79
SPECIFICATIONS -----	5- 1
SPECIFICATIONS -----	5- 2
ATTACHMENTS AND OPTIONS -----	6- 1
ATTACHMENTS AND OPTIONS - GENERAL INFORMATION -----	6- 2
SAFETY FIRST -----	6- 2
ATTACHMENT INSTALLATION -----	6- 3
BUCKET WITH HOOK -----	6- 4
HOOK CONDITION -----	6- 4
PROHIBITED OPERATIONS -----	6- 4
MACHINE READY FOR ATTACHMENT -----	6- 5
LOCATIONS -----	6- 5
HYDRAULIC CIRCUIT -----	6- 8
ATTACHMENT REMOVAL AND INSTALLATION -----	6- 9
ATTACHMENT OPERATIONS -----	6- 13
LONG TERM STORAGE -----	6- 17
SPECIFICATIONS -----	6- 17
ATTACHMENT GUIDE -----	6- 18
ATTACHMENT COMBINATIONS -----	6- 19
TRACK SHOES SELECTION -----	6- 20
RECOMMENDED ATTACHMENT OPERATIONS -----	6- 21
HYDRAULIC BREAKER -----	6- 21
HANDLING MACHINES EQUIPPED WITH KOMTRAX -----	6- 26
BASIC PRECAUTIONS -----	6- 26
INDEX -----	7- 1

### Monitor Switches Portion




9JH09215

- (1) Working mode selector switch
- (2) Auto-deceleration switch
- (3) Travel speed selector switch
- (4) Wiper switch

- (5) Window washer switch
- (6) Buzzer cancel switch
- (7) Function switches
- (8) Air conditioner switch

**Cleaning Recirculated Air Filter**

1. Open cover (1) at the front bottom left of the operator's seat.
2. Take out internal filter (2).
3. Clean internal filter (2) with compressed air. If there is oil stuck to the filter (2) or it is extremely dirty, wash it in a neutral agent. After washing, dry it thoroughly before using it again.




**REMARK**

If the clogging of the filter cannot be removed by blowing it with compressed air or washing in water, replace the filter with a new one.

4. After cleaning filter (2), return it to its original position and close cover (1).


**Cleaning Fresh Air Filter**

1. Use the starting key to unlock cover (1) at the rear left of the operator's cab, open cover (1) by hand, secure it in position with cover support lever (3), then remove filter (2) from the inside.
2. Clean the filter with compressed air. If there is oil on the filter, or if the filter is extremely dirty, wash it in a neutral agent. After rinsing it in water, dry it thoroughly before using it again. Replace the filter with a new part every year. If the clogging of the filter cannot be removed by blowing with air or washing in water, replace the filter immediately.
3. After cleaning, return filter (2) to its original place, remove cover support lever (3), and close the cover. When doing this, lock it with the starting key. After locking it, do not forget to remove the starting key.





**REMARK**

The FRESH filter must be installed facing in the correct direction. When installing, insert the long (L) end of filter (2) into the filter case first. If the short (S) end is installed first, cover (1) will not close.



6. Remove cover (1) at the top surface of the hydraulic tank, then slowly loosen oil filler cap (F) to release the internal pressure.




7. After checking that the oil temperature is low, remove the covers from the inlet port and outlet port (2 places). Be careful that no dirt or mud is stuck to the hose mouthpiece. If the O-ring is damaged, replace it with a new part.

8. Connect the hose at the attachment side.


When doing this, check the direction of flow of the oil and be careful not to make any mistake.

9. Set the rotor of the stop valve installed to the inlet port on the side face of the arm and the outlet port piping to FREE position (a).

- (a) FREE: Hydraulic oil flows (direction of arrow is parallel to long direction of arm)
- (b) LOCK: Hydraulic oil does not flow (direction of arrow is at right angles to long direction of arm)



- When setting the FREE or LOCK position of the stop valve rotor, remove bolt (2), turn over plate (1), then turn the rotor. After setting, install plate (1) again with bolt (2).



10. After installing the attachment, check the oil level in the hydraulic tank.



INDEX

<A>		<F>	
AFTER STARTING ENGINE .....	3-138	FIRE EXTINGUISHER .....	3-113
AIR CONDITIONER CONTROLS .....	3- 90	FOREWORD .....	1- 2
ASHTRAY .....	3-113	FUSE .....	3-108
ATTACHMENT GUIDE .....	6- 18	FUSIBLE LINK .....	3-109
ATTACHMENT COMBINATIONS .....	6- 19	<G>	
TRACK SHOES SELECTION .....	6- 20	GENERAL OPERATION INFORMATION ---	3-162
ATTACHMENTS AND OPTIONS -		GENERAL PRECAUTIONS .....	2- 13
GENERAL INFORMATION .....	6- 2	GREASE PUMP HOLDER .....	3-112
ATTACHMENT INSTALLATION .....	6- 3	<H>	
SAFETY FIRST .....	6- 2	HANDLING MACHINES EQUIPPED	
AUXILIARY ELECTRIC POWER .....	3-110	WITH KOMTRAX .....	6- 26
<B>		BASIC PRECAUTIONS .....	6- 26
BEFORE STARTING ENGINE .....	3-114	HANDLING OIL, FUEL, COOLANT, AND	
BREAKING-IN THE NEW MACHINE .....	1- 7	PERFORMING OIL CLINIC .....	4- 4
BUCKET REPLACEMENT AND		<I>	
INVERSION .....	3-170	INTRODUCTION .....	1- 7
BUCKET WITH HOOK .....	6- 4	<L>	
HOOK CONDITION .....	6- 4	LIFTING MACHINE .....	3-186
PROHIBITED OPERATIONS .....	6- 4	LOADING AND UNLOADING WITH	
<C>		TRAILER .....	3-179
CAB REAR COVER .....	3- 87	LOCKING .....	3-175
CAP WITH LOCK .....	3- 85	LONG TERM STORAGE .....	3-191
COLD WEATHER OPERATION .....	3-188	AFTER STORAGE .....	3-192
AFTER COLD WEATHER SEASON .....	3-190	BEFORE STORAGE .....	3-191
AFTER DAILY WORK COMPLETION .....	3-189	DURING STORAGE .....	3-192
COLD WEATHER OPERATION		STARTING MACHINE AFTER	
INFORMATION .....	3-188	LONG-TERM STORAGE .....	3-192
CONTROL LEVERS AND PEDALS .....	3- 73	<M>	
CONTROLLERS .....	3-111	MACHINE INSPECTION AFTER DAILY	
CONTROLS AND GAUGES .....	3- 3	WORK .....	3-174
CUP HOLDER .....	3-112	MACHINE OPERATION .....	3-150
<D>		MACHINE OPERATIONS AND	
DETAILED CONTROLS AND GAUGES ....	3- 5	CONTROLS .....	3-114
DIRECTIONS OF MACHINE .....	1- 7	MACHINE READY FOR ATTACHMENT ....	6- 5
DOOR AT FRONT OF TOOL BOX .....	3- 89	ATTACHMENT OPERATIONS .....	6- 13
<E>		HYDRAULIC CIRCUIT .....	6- 8
ELECTRIC SYSTEM MAINTENANCE .....	4- 7	LOCATIONS .....	6- 5
EMERGENCY ESCAPE HAMMER .....	3- 84	LONG TERM STORAGE .....	6- 17
ENGINE HOOD .....	3- 86	SPECIFICATIONS .....	6- 17
EPA REGULATIONS, ENGINE NUMBER		MACHINE VIEW ILLUSTRATIONS .....	3- 2
PLATE .....	1- 8	OVERALL MACHINE VIEW .....	3- 2
ESCAPE FROM MUD .....	3-167		

MAINTENANCE INFORMATION -----	4- 2	SAFETY CRITICAL PARTS -----	4- 13
MAINTENANCE PROCEDURE -----	4- 17	SAFETY CRITICAL PARTS LIST -----	4- 13
CHECK BEFORE STARTING -----	4- 46	SAFETY INFORMATION -----	1- 5
EVERY 100 HOURS MAINTENANCE ---	4- 47	SAFETY LABELS -----	2- 4
EVERY 1000 HOURS MAINTENANCE --	4- 65	LOCATION OF SAFETY LABELS -----	2- 5
EVERY 2000 HOURS MAINTENANCE --	4- 71	SAFETY LABELS -----	2- 6
EVERY 250 HOURS MAINTENANCE ---	4- 49	SAFETY MACHINE OPERATION -----	2- 22
EVERY 4000 HOURS MAINTENANCE --	4- 75	BATTERY -----	2- 31
EVERY 500 HOURS MAINTENANCE ---	4- 56	LIFTING OBJECTS WITH BUCKET -----	2- 34
EVERY 5000 HOURS MAINTENANCE --	4- 77	OPERATION -----	2- 24
EVERY 8000 HOURS MAINTENANCE --	4- 79	STARTING ENGINE -----	2- 22
WHEN REQUIRED -----	4- 17	TOWING -----	2- 33
MAINTENANCE SCHEDULE -----	4- 14	TRANSPORTATION -----	2- 30
MAINTENANCE INTERVAL FOR		SAFETY MAINTENANCE	
HYDRAULIC BREAKER -----	4- 16	INFORMATION -----	2- 35
MAINTENANCE SCHEDULE CHART ----	4- 14	SERVICE METER LOCATION -----	1- 9
MONITORING SYSTEM -----	3- 5	SLIDING DOOR -----	3- 83
		SPECIFICATIONS -----	5- 2
<O>		STARTING ENGINE -----	3-133
OPERATION MANUAL STORAGE -----	3-112	STEERING THE MACHINE -----	3-154
OUTLINE OF SERVICE -----	4- 4	STOPPING THE ENGINE -----	3-149
		SUN ROOF -----	3- 77
<P>		SWINGING -----	3-156
PARKING MACHINE -----	3-173	SWITCHES -----	3- 68
PRODUCT IDENTIFICATION NUMBER			
(PIN)/MACHINE SERIAL NO. PLATE -----	1- 8	<T>	
PRODUCT INFORMATION -----	1- 8	TIGHTENING TORQUE LIST -----	4- 12
PROHIBITED OPERATIONS -----	3-160	TIGHTENING TORQUE	
PUMP ROOM DOOR, BATTERY ROOM		SPECIFICATIONS -----	4- 12
DOOR -----	3- 88	TOOL BOX -----	3-112
		TRANSPORTATION -----	3-178
<R>		TRANSPORTATION PROCEDURE -----	3-178
RADIO -----	3-103	TRAVELING ON SLOPES -----	3-165
RECOMMENDED APPLICATIONS -----	3-168	TROUBLES AND ACTIONS -----	3-193
RECOMMENDED ATTACHMENT		DISCHARGED BATTERY -----	3-196
OPERATIONS -----	6- 21	LIGHTWEIGHT TOWING HOOK -----	3-195
HYDRAULIC BREAKER -----	6- 21	OTHER TROUBLE -----	3-201
RECOMMENDED FUEL, COOLANT,		PHENOMENA THAT ARE NOT	
AND LUBRICANT -----	4- 9	FAILURES -----	3-193
RECOMMENDED BRANDS,		RUNNING OUT OF FUEL -----	3-193
RECOMMENDED QUALITY FOR		SEVERE JOB CONDITION -----	3-195
PRODUCTS OTHER THAN		TOWING THE MACHINE -----	3-194
KOMATSU GENUINE OIL -----	4- 11		
USE OF FUEL, COOLANT AND		<W>	
LUBRICANTS ACCORDING TO		WEAR PARTS -----	4- 8
AMBIENT TEMPERATURE -----	4- 10	WEAR PARTS LIST -----	4- 8
ROAD LINERS -----	3-176	WINDSHIELD -----	3- 77
		WORK EQUIPMENT CONTROLS AND	
<S>		OPERATIONS -----	3-157
SAFETY -----	2- 2	WORKING MODE -----	3-159

# Shop Manual

HYDRAULIC  
EXCAVATOR

**GALEO**

**PC138US -8**

**PC138USLC-8**

SERIAL NUMBERS    PC138US- 20001    and up  
PC138USLC-20001

**ecot3**

**KOMATSU**

## Table of contents

00 Index and foreword	
Index	SEN01977-02
Composition of shop manual.....	2
Table of contents.....	4
Foreword and general information	SEN01978-01
Safety notice.....	2
How to read the shop manual.....	7
Explanation of terms for maintenance standard.....	9
Handling of electric equipment and hydraulic component.....	11
Handling of connectors newly used for engines.....	20
How to read electric wire code.....	23
Precautions when carrying out operation.....	26
Method of disassembling and connecting push-pull type coupler.....	29
Standard tightening torque table.....	32
Conversion table.....	36
01 Specification	
Specification and technical data	SEN01979-01
Specification dimension drawings.....	2
Working range diagram.....	3
Specifications.....	4
List of weights.....	10
Table of fuel, coolant and lubricants.....	14
10 Structure, function and maintenance standard	
Engine and cooling system	SEN02545-01
Engine mount.....	2
PTO.....	3
Cooling system.....	4
Power train	SEN02546-01
Power train.....	2
Swing circle.....	3
Swing machinery.....	4
Undercarriage and frame	SEN02547-01
Track frame.....	2
Idler cushion.....	4
Idler.....	6
Track roller.....	7
Carrier roller.....	8
Sprocket.....	9
Track shoe.....	10
Hydraulic system, Part 1	SEN02548-01
Hydraulic equipment layout drawing.....	2
Valve control.....	4
Hydraulic tank and filter.....	6
Hydraulic pump.....	8
Hydraulic system, Part 2	SEN02549-02
Control valve.....	2
CLSS.....	14
Functions and operation by valve.....	18
Hydraulic system, Part 3	SEN02550-01
PPC valve.....	2

Swing motor .....	19
Travel motor .....	27
Center swivel joint .....	36
Solenoid valve .....	40
PPC accumulator .....	44
Holding valve .....	46
Multi-control valve .....	51
Work equipment .....	SEN02551-00
Work equipment .....	2
Dimensions of components .....	4
Hydraulic cylinder .....	8
Cab and its attachments .....	SEN02552-01
Air conditioner .....	2
Electrical system .....	SEN02553-01
Electronic control system .....	2
Monitor system .....	35
KOMTRAX system .....	49
Sensor .....	51
20 Standard value table .....	
Standard service value table .....	SEN02457-01
Standard value table for engine related parts .....	2
Standard value table for chassis related parts .....	3
30 Testing and adjusting .....	
Testing and adjusting, Part 1 .....	SEN02458-01
Tools for testing, adjusting, and troubleshooting .....	3
Testing engine speed .....	6
Testing exhaust temperature .....	7
Checking exhaust gas color .....	8
Adjusting valve clearance .....	9
Testing compression pressure .....	11
Testing blow-by pressure .....	13
Testing engine oil pressure .....	14
Handling fuel system parts .....	15
Releasing residual pressure from fuel system .....	15
Testing fuel pressure .....	16
Testing fuel return rate and fuel leakage .....	17
Bleeding air from fuel circuit .....	19
Checking fuel circuit for leakage .....	21
Testing and adjusting alternator belt tension .....	22
Testing swing circle bearing clearance .....	23
Checking and adjusting air conditioner compressor belt tension .....	24
Checking and adjusting track shoe tension .....	25
Testing and adjusting oil pressure in work equipment, swing, and travel circuits .....	27
Testing control circuit basic pressure .....	30
Testing and adjusting oil pressure in pump PC control circuit .....	31
Testing and adjusting oil pressure in pump LS control circuit .....	34
Testing solenoid valve output pressure .....	38
Testing PPC valve output pressure .....	39
Adjusting play of work equipment and swing PPC valves .....	41
Checking parts which cause hydraulic drift of work equipment .....	42
Testing and adjusting travel deviation .....	44
Releasing residual pressure from hydraulic circuit .....	46
Testing oil leakage .....	47
Bleeding air from each part .....	50

Checking cab tipping stopper .....	52
Adjusting mirrors .....	52
Testing and adjusting, Part 2 .....	SEN02459-00
Special functions of machine monitor .....	2
Testing and adjusting, Part 3 .....	SEN02460-01
Handling voltage circuit of engine controller .....	2
Preparation work for troubleshooting of electrical system .....	3
Procedure for testing diodes .....	8
Pm Clinic service .....	9
 40 Troubleshooting	
Failure code table and fuse locations .....	SEN02461-01
Failure code table .....	2
Fuse locations .....	6
General information on troubleshooting .....	SEN02462-00
Points to remember when troubleshooting .....	2
Sequence of events in troubleshooting .....	3
Checks before troubleshooting .....	4
Classification and procedures for troubleshooting .....	5
Information in troubleshooting table .....	6
Phenomena looking like troubles and troubleshooting Nos. ....	8
Wiring table for connector pin numbers .....	11
T-adaptor box and T-adaptor table .....	44
Troubleshooting by failure code, Part 1 .....	SEN02463-01
Failure code [989L00] Engine controller lock caution 1 .....	3
Failure code [989M00] Engine controller lock caution 2 .....	3
Failure code [989N00] Engine controller lock caution 3 .....	4
Failure code [AB00KE] Charge voltage low .....	6
Failure code [B@BAZG] Eng oil press. low .....	8
Failure code [B@BAZK] Eng oil level low .....	8
Failure code [B@BCNS] Eng coolant overheat .....	9
Failure code [B@HANS] Hydr oil overheat .....	9
Failure code [CA111] ECM critical internal failure .....	10
Failure code [CA115] Eng. Ne and Bkup speed sensor error .....	13
Failure code [CA122] Charge air press sensor high error .....	14
Failure code [CA123] Charge air press sensor low error .....	16
Failure code [CA131] Throttle sensor high error .....	18
Failure code [CA132] Throttle sensor low error .....	20
Failure code [CA144] Coolant temp. sensor high error .....	21
Failure code [CA145] Coolant temp. sensor low error .....	22
Failure code [CA153] Charge air temp. sensor high error .....	23
Failure code [CA154] Charge air temp. sensor low error .....	24
Failure code [CA187] Sensor sup. 2 volt. low error .....	24
Failure code [CA221] Ambient air press. sensor high error .....	26
Failure code [CA222] Ambient air press. sensor low error .....	28
Failure code [CA227] Sensor sup. 2 volt. high error .....	30
Failure code [CA234] Eng. overspeed .....	32
Failure code [CA238] Ne speed sensor sup. volt. error .....	34
Failure code [CA271] IMV/PCV1 short error .....	36
Failure code [CA272] IMV/PCV1 open error .....	37
Failure code [CA322] Injector #1 (L #1) system open/short error .....	38
Failure code [CA324] Injector #3 (L/B #3) system open/short error .....	40
Failure code [CA331] Injector #2 (L/B #2) system open/short error .....	42
Failure code [CA332] Injector #4 (L/B #4) system open/short error .....	44
Troubleshooting by failure code, Part 2 .....	SEN02464-01
Failure code [CA351] Inj. drive circuit error .....	3

Failure code [CA352] Sensor sup. 1 volt. low error.....	6
Failure code [CA386] Sensor sup. 1 volt. high error.....	8
Failure code [CA435] Abnormality in engine oil pressure switch.....	10
Failure code [CA441] Battery voltage low error.....	11
Failure code [CA442] Battery voltage high error.....	11
Failure code [CA449] Rail press. very high error.....	12
Failure code [CA451] Rail press. sensor high error.....	14
Failure code [CA452] Rail press. sensor low error.....	16
Failure code [CA553] Rail press. high error.....	16
Failure code [CA559] Rail press. low error.....	17
Failure code [CA689] Eng. Ne speed sensor error.....	20
Failure code [CA731] Eng. Bkup speed sensor phase error.....	22
Failure code [CA757] All persistent data lost error.....	22
Failure code [CA778] Eng. Bkup speed sensor error.....	24
Failure code [CA1633] KOMNET datalink timeout error.....	26
Failure code [CA2185] Throttle sens. sup. volt. high error.....	28
Failure code [CA2186] Throttle sens. sup. volt. low error.....	30
Failure code [CA2249] Rail press. very low error.....	30
Failure code [CA2311] Abnormality in IMV solenoid.....	31
Failure code [D110KB] Battery relay drive short.....	32
Failure code [D19JKZ] Personal code relay abnormality.....	34
Failure code [D862KA] GPS antenna discon.....	36
Failure code [DA22KK] Pump solenoid power low error.....	38
Failure code [DA25KP] 5V sensor 1 power abnormality.....	40
Failure code [DA26KP] 5V sensor 2 power abnormality.....	43
Troubleshooting by failure code, Part 3.....	SEN02465-01
Failure code [DA2RMC] CAN discon (Pump controller detected).....	4
Failure code [DAF8KB] Short circuit in camera power supply.....	6
Failure code [DAFGMC] GPS module error.....	8
Failure code [DAFRMC] CAN discon (Monitor detected).....	10
Failure code [DGH2KB] Hydr oil sensor short.....	12
Failure code [DHPAMA] Pump press sensor abnormality.....	14
Failure code [DHSFMA] Travel left forward PPC press sensor abnormality.....	16
Failure code [DHSGMA] Travel right forward PPC press sensor abnormality.....	18
Failure code [DHSHMA] Travel left reverse PPC press sensor abnormality.....	20
Failure code [DHSJMA] Travel right reverse PPC press sensor abnormality.....	22
Failure code [DHSMMA] Blade raise PPC press sensor abnormality.....	24
Failure code [DHSLMA] Blade lower PPC press sensor abnormality.....	26
Failure code [DHX1MA] Overload sensor abnormality (Analog).....	28
Failure code [DV20KB] Travel alarm S/C.....	29
Failure code [DW43KA] Travel speed sol discon.....	30
Failure code [DW43KB] Travel speed sol short.....	31
Failure code [DW45KA] Swing brake sol discon.....	32
Failure code [DW45KB] Swing brake sol short.....	34
Failure code [DW91KA] Travel junction sol discon.....	36
Failure code [DW91KB] Travel junction sol short.....	37
Failure code [DWJ0KA] Merge-divider sol discon.....	38
Failure code [DWJ0KB] Merge-divider sol short.....	39
Troubleshooting by failure code, Part 4.....	SEN02466-00
Failure code [DXA8KA] PC-EPC sol discon.....	2
Failure code [DXA8KB] PC-EPC sol short.....	4
Failure code [DXE4KA] Service current EPC discon.....	6
Failure code [DXE4KB] Service current EPC short.....	7
Failure code [DY20KA] Wiper working abnormality.....	8
Failure code [DY20MA] Wiper parking abnormality.....	10
Failure code [DY2CKA] Washer drive discon.....	12
Failure code [DY2CKB] Washer drive short.....	14

Failure code [DY2DKB] Wiper drive (for) short .....	16
Failure code [DY2EKB] Wiper drive (rev) short.....	18
Troubleshooting of electrical system (E-mode) .....	SEN02467-00
Before carrying out troubleshooting of electrical system.....	3
Information in troubleshooting table .....	5
E-1 When starting switch turned ON, machine monitor displays nothing.....	6
E-2 When starting switch turned ON (before starting engine), basic check item lights up .....	8
E-3 Engine does not start (Engine does not turn) .....	9
E-4 Preheater does not operate .....	12
E-5 Automatic warm-up system does not operate (in cold season).....	14
E-6 All work equipment, swing, and travel mechanism do not move or cannot be locked.....	16
E-7 Precaution lights up while engine is running.....	18
E-8 Emergency stop item lights up while engine is running .....	21
E-9 Engine coolant temperature gauge does not indicate normally.....	22
E-10 Hydraulic oil temperature gauge does not indicate normally .....	23
E-11 Fuel level gauge does not indicate normally .....	25
E-12 Contents of display by machine monitor are different from applicable machine.....	27
E-13 Machine monitor does not display some items.....	27
E-14 Function switch does not work.....	27
E-15 Auto-decelerator does not operate normally.....	28
E-16 Working mode does not change .....	29
E-17 Travel speed does not change.....	30
E-18 Alarm buzzer cannot be stopped .....	31
E-19 Windshield wiper and window washer do not operate.....	32
E-20 Swing holding brake does not operate normally.....	36
E-21 Travel alarm does not sound or does not stop sounding .....	38
E-22 Air conditioner does not operate normally (including air conditioner abnormality record) ..	39
E-23 While starting switch is in OFF position, service meter is not displayed.....	51
E-24 Machine monitor cannot be set in service mode .....	51
E-25 Monitoring function does not display lever control signal normally.....	52
E-26 KOMTRAX system does not operate normally .....	68
Troubleshooting of hydraulic and mechanical system (H-mode) .....	SEN02468-01
Information contained in troubleshooting table.....	3
System chart for hydraulic and mechanical systems .....	4
H-1 Speed or power of all work equipment, swing, and travel are low.....	6
H-2 Engine speed sharply drops or engine stalls.....	7
H-3 No work equipment, travel and swing move.....	8
H-4 Abnormal noise is heard from around hydraulic pump .....	8
H-5 Fine control mode does not function .....	9
H-6 Speed or power of boom is low .....	10
H-7 Speed or power of arm is low .....	11
H-8 Speed or power of bucket is low.....	12
H-9 Work equipment does not move in its single operation .....	13
H-10 Hydraulic drift of work equipment is large.....	14
H-11 Time lag of work equipment is large .....	15
H-12 Work equipment loaded more is slower during compound operation.....	15
H-13 Boom RAISE speed is low in compound operation of swing + boom RAISE .....	15
H-14 Travel speed lowers largely during compound operation of work equipment/swing + travel ..	16
H-15 Machine deviates during travel.....	17
H-16 Travel speed is low.....	18
H-17 Machine cannot be steered easily or steering power is low .....	19
H-18 Travel speed does not change or it is kept low or high.....	20
H-19 Track does not move (Only either side).....	20
H-20 Machine does not swing .....	21
H-21 Swing acceleration or swing speed is low .....	22
H-22 Excessive overrun when stopping swing.....	23
H-23 When upper structure stops swinging, it makes large shock.....	24



H-24 When upper structure stops swinging, it makes large sound .....	24
H-25 Hydraulic drift of swing is large.....	25
H-26 Flow rate in attachment circuit cannot be adjusted .....	26
Troubleshooting of engine (S-mode) .....	SEN02469-01
Method of using troubleshooting chart .....	4
S-1 Starting performance is poor .....	8
S-2 Engine does not start.....	9
S-3 Engine does not pick up smoothly .....	12
S-4 Engine stops during operations .....	13
S-5 Engine does not rotate smoothly .....	14
S-6 Engine lacks output (or lacks power).....	15
S-7 Exhaust smoke is black (incomplete combustion).....	16
S-8 Oil consumption is excessive (or exhaust smoke is blue) .....	17
S-9 Oil becomes contaminated quickly .....	18
S-10 Fuel consumption is excessive .....	19
S-11 Oil is in coolant (or coolant spurts back or coolant level goes down) .....	20
S-12 Oil pressure drops .....	21
S-13 Oil level rises (Entry of coolant or fuel).....	22
S-14 Coolant temperature becomes too high (overheating) .....	23
S-15 Abnormal noise is made .....	24
S-16 Vibration is excessive .....	25
50 Disassembly and assembly .....	
General information on disassembly and assembly .....	SEN02709-00
How to read this manual .....	2
List of adhesives .....	4
Special tool list .....	7
Sketches of special tool .....	11
Engine and cooling system .....	SEN02710-00
Removal and installation of fuel supply pump assembly.....	2
Removal and installation of fuel injector assembly .....	4
Removal and installation of front oil seal.....	7
Removal and installation of rear oil seal .....	9
Removal and installation of cylinder head assembly .....	12
Removal and installation of radiator assembly.....	19
Removal and installation of aftercooler assembly .....	21
Removal and installation of work equipment oil cooler assembly .....	23
Removal and installation of engine and work equipment pump assembly.....	26
Removal and installation of fuel tank assembly .....	31
Power train .....	SEN02711-00
Removal and installation of travel motor and final drive assembly .....	2
Removal and installation of swing motor and swing machinery assembly.....	4
Disassembly and assembly of swing machinery assembly.....	6
Removal and installation of swing circle assembly .....	12
Undercarriage and frame .....	SEN02712-00
Disassembly and assembly of track roller.....	2
Disassembly and assembly of idler assembly.....	5
Disassembly and assembly of recoil spring .....	8
Removal and installation of track shoe assembly .....	11
Removal and installation of sprocket .....	13
Removal and installation of revolving frame assembly .....	14
Removal and installation of counterweight assembly (Machine without add-on weight).....	16
Removal and installation of counterweight assembly (Machine with add-on weight).....	18
Hydraulic system .....	SEN02713-00
Removal and installation of center swivel joint assembly .....	2
Disassembly and assembly of center swivel joint assembly .....	4

Removal and installation of hydraulic tank assembly .....	5
Removal and installation of hydraulic pump assembly.....	8
Removal and installation of control valve assembly .....	12
Disassembly and assembly of control valve assembly .....	17
Disassembly and assembly of work equipment PPC valve assembly .....	27
Disassembly and assembly of travel PPC valve assembly .....	30
Disassembly and assembly of hydraulic cylinder assembly.....	32
Work equipment Body	SEN02714-00
Removal and installation of work equipment assembly.....	2
Cab and its attachments	SEN02715-00
Removal and installation of operator cab assembly .....	2
Removal and installation of operator's cab glass (stuck glass).....	4
Removal and installation of front window assembly .....	13
Removal and installation of floor frame assembly.....	14
Electrical system	SEN02716-00
Removal and installation of air compressor assembly .....	2
Removal and installation of air conditioner condenser.....	3
Removal and installation of air compressor unit assembly .....	4
Removal and installation of machine monitor assembly .....	7
Removal and installation of pump controller assembly .....	8
Removal and installation of engine controller assembly .....	9
Removal and installation of KOMTRAX communications module.....	10
90 Diagrams and drawings	
Hydraulic circuit diagram	SEN01980-00
Hydraulic circuit diagram .....	3
Electrical diagrams and drawings	SEN01981-01
Electrical circuit diagram .....	3
Connectors table and arrangement drawing .....	5


### 3. Push lock type

- 107, 114 engines  
Example)  
Fuel pressure sensor in common rail  
(**BOSCH-03**)



Disconnect connector (3) according to the following procedure.

- 1) While pressing lock (C), pull out connector (3) in the direction of the arrow.

- 114 engine




- 107 engine



- 107, 114 engine  
Example)  
Intake air pressure/temperature sensor in intake manifold  
(**SUMITOMO-04**)


- 3) While pressing lock (D), pull out connector (4) in the direction of the arrow.



★ If the lock is on the underside, use flat-head screwdriver [1] since you cannot insert your fingers.

- 2) While pressing up lock (C) of the connector with flat-head screwdriver [1], pull out connector (3) in the direction of the arrow.


Valve control



9JB04149

- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li>1. Connecting valve</li> <li>2. Solenoid valve</li> <li>3. Accumulator (for PPC circuit)</li> <li>4. Control valve</li> <li>5. Blade PPC valve (blade specification)</li> <li>6. R.H. work equipment control lever (for boom and bucket control)</li> <li>7. Blade control lever (blade specification)</li> <li>8. L.H. work equipment control lever (for arm and swing control)</li> <li>9. L.H. work equipment PPC valve</li> </ul> | <ul style="list-style-type: none"> <li>10. Lock lever</li> <li>11. R.H. work equipment PPC valve</li> <li>12. Travel lever</li> <li>13. Travel pedal</li> <li>14. Travel PPC valve</li> <li>15. Attachment PPC valve (Machine ready for attachment)</li> <li>16. Attachment control pedal (Machine ready for attachment)</li> <li>17. Lock pin</li> </ul> |
|--|---|

## 2. When boom and arm are set in neutral



9JS07391

### Operation

- If the control lever is returned to the neutral position while the boom is raised out, the holding pressure in the boom cylinder bottom and arm cylinder head is blocked by poppet (5) and the pressurized oil flowing in through orifice (a) is blocked by pilot spool (3). Accordingly, the boom is held.


## 2. When pressurized oil flows from the main valve to the cylinder

### When the piping is free of breakage

- Pressurized oil led to chamber (a) from the control valve becomes higher than the combined force of pressure from work equipment cylinder circuit chamber (b) and spring (6).
- Check valve (5) opens and chambers (a) and (b) are interconnected.
- Pressurized oil flows from the control valve to the work equipment cylinder.

### If the piping is bursted

- If piping (A) between the control valve and the work equipment cylinder is broken, pressurized oil in chamber (a) flows outside from the damaged portion.
- Pressure force in chamber (a) drops.
- Pressure force in chamber (a) drops lower than the combined pressure force of chamber (b) and spring (6).
- Check valve (5) closes and chambers (a) and (b) are cut off.
- Pressure for the work equipment cylinder is held to prevent a sudden drop of the work equipment.




## Removal and installation of of track shoe assembly

### Special tools


Sym- bol	Part No.	Part name	Necessity	New/Remodel	
				Q'ty	
R	791-616-1110	Frame	■	1	
	791-616-1121	Plate	■	1	
	791-616-1131	Plate	■	1	
	791-616-1150	Guide	■	1	
	791-616-1160	Adapter	■	1	
	791T-616-1280	Adapter	■	1	
	791-620-3530	Push	■	1	
	791-620-3260	Push	■	1	
	791-620-3270	Guide	■	1	
	01011-62260	Bolt	■	2	
	01643-62260	Washer	■	2	
	01011-61455	Bolt	■	3	
	01643-31445	Washer	■	3	
	790-105-1100	Cylinder (297 kN {30 ton})	■	1	
	790-101-1102	Pump	■	1	

2. Move machine forward so that position of master pin is at front of idler, and set block [1] in position.
3. Using tool **R**, pull out master pin. [\*2]
4. Remove tool **R**, pull out temporary pin, and remove dust seal, then drive machine in reverse to lay out track (2). [\*3]



### Removal

1. Lower work equipment to ground, then loosen lubricator (1), and relieve track tension. [\*1]  
**⚠ The adjustment cylinder is under extremely high pressure. Never loosen the lubricator more than one turn. If the grease does not come out, move the machine backwards and forwards.**



## Removal and installation of pump controller assembly


### Removal

⚠ **Disconnect the negative (-) terminal of the battery beforehand.**



1. Remove cover (1).



2. Remove cover (2).
3. Remove duct (3).
4. Remove cover (4).



5. Disconnect wiring (5) and (6).
  - ★ Pull each connector lever (a) and (b) inward.
6. Remove 4 mounting bolts (7) and 2 mounting bolts (8), and remove pump controller assembly (9).



### Installation

- Carry out the installation in the reverse order of removal.