



ALPINE 65 - 75 - 85

TRAINING MANUAL
P/N 3676095M1 - EDITION 03-2005

Landini




TABLE OF CONTENTS

	Section N°	Edition
1 GENERAL INFORMATION		
General information	100	03-2005
2 ENGINE		
Engine	200	03-2005
3 CLUTCH		
Clutch	300	03-2005
4 GEARBOX		
Speedfive and Powerfive mechanical gearbox	400	03-2005
5 TRANSMISSION		
Rear axle and side final drives	500	03-2005
Front axle	510	03-2005
6 POWER TAKE-OFF		
Power take-off	600	03-2005
7 HYDRAULIC SYSTEMS		
Hydraulic systems - Rear power lift	700	03-2005
8 STEERING		
Steering	800	03-2005
9 BRAKES		
Brakes	900	03-2005
10 ELECTRICAL SYSTEMS		
Electrical system - Instruments	1000	03-2005
Electrical system - Components	1010	03-2005
Electrical system - Ignition system	1020	03-2005
Electrical system - Recharging system	1030	03-2005
Electrical system - Battery	1040	03-2005
Electrical system - Electrical circuits	1050	03-2005
11 CAB		
Cab and A/C system	1100	03-2005




5. Remove the crown (1) with the help of a lever.




28

6. Remove the ring (1).




29

7. Remove the three circlips (1) using a 8 MA screw, remove the three pins (2) with stop rollers from the cover (3).




30

8. Remove from the central hole the three satellites (1), the slewing bearings (2) and the respective roller bearings (3).



31




General hydraulic circuit

**Step with parking brake applied and brake pedals released**

By activating the parking brake via the tie-rod "M", communication is effected between the exhaust "T" and the chamber "S" inside the tie-rod; being the latter connected to the chamber "H" which feeds the trailer, has practically no pressure. The auto-

matic trailer braking device is released in this way. The oil from the pump, in addition to being conveyed into chamber "D", feeds the hydraulic power lift via the pipe "N" put into communication by groove "C".




SLA0228

18

- A. Trailer brake connection quick connection
- B. Distributor activation piston
- C. Pump-power lift connection groove
- D. Chamber
- E1. Pressure switch
- E2. Pressure switch
- F. Chamber
- G. 140 bar pressure hold spring
- G1. 10-15 bar pressure hold spring
- G2. Sleeve return spring (W)
- G3. Piston spring (L)
- H. Trailer brake outlet chamber
- K. 10-15 bar pressure adjustment shims

- K1. Piston stroke adjustment shims (Q)
- K2. 140 bar pressure adjustment shims
- L. Trailer brake feeding command piston
- M. Parking brake connection tie-rod
- N. Power lift feeding
- O. Return piston
- P. Pump feed
- Q. Main piston
- R. Trailer brake feeding channel
- S. Brake tie-rod inner channel
- T. Discharge channel
- W. Sleeve
- Y. Tractor brake feed



5LA0281

78

Check valve leakage inspection

Another cause of leakage may be the check valve (12). To facilitate location and to define the entity of the leakage, remove the maximum valve (13) which is in direct communication with the check valve delivery pipe (12). Oil cannot be let out from the respective pipe directly in this way.

If this occurs, lap the seat with fine emery to recreate tightness.



Do not attempt to recreate the seats by hitting the balls or the valves because this would only cause stretching and possible oil leakage.



Maximum valve inspection and calibration


This test must be performed with tool (1) **120 IDR GL**. Move the pump delivery pipe (2) to the lower union (3) and fasten the closing plug on the union (4) used for the previous test.

1. Fit the previously removed maximum valve (13) on the distributor.
2. Extend the tool (5) **121 IDR GL** turning it by one turn and a half with respect to the previous

condition to take the distributor to delivery step.


3. Operate the pump and make the maximum valve (13) open. This opening must occur at 180 bars.

If you need to adjust the valve, turn the adjustment screw (14) to increase the pressure and loosen it to decrease it.




5LA0280

79




**Delivery pipe leakage inspection**

1. Keeping the distributor in the previous conditions, operate the pump and take the pressure in the circuit to 120 bars.
2. Check tightness of the valve (13): there must be no oil leakage. If this does not occur, lap with fine emery the seat to provide perfect tightness again.
3. Check tightness of the regulator piston (15). The maximum admitted leakage is 15 cm³ in 1 minute. If oil leaks from pipe (7), this is due to the play between the upper part (6) of the rod (7) and the distributor body. It will not be due to the discharge valve (8) as this has already been checked. The maximum leakage is 10 cm³ in 1 minute.





81






- | | |
|------------------------------|-----------------------------------|
| 1. Check valve | 16. Ring |
| 2. One-way valve | 17. Washer |
| 3. Stator | 18. Anti-shock valve |
| 4. Rotor | 19. Roller bearing |
| 5. Screw | 20. Washer |
| 6. Spacer | 21. O-ring |
| 7. Screw | 22. Ring |
| 8. Seal | 23. Centring springs |
| 9. Closing plate | 24. O-ring |
| 10. O-ring | 25. "Orbitrol" distributor |
| 11. O-ring | 26. Pin |
| 12. Distributor plate | 27. Sleeve |
| 13. O-ring | 28. Anti-cavitation valve |
| 14. Connection shaft | 29. Safety valve |
| 15. Drum | |



5LA0317

ORBITROL distributor prospective view

- | | |
|-----------------------|----------------------------|
| 1. Check valve | 16. Ring |
| 2. One-way valve | 17. Washer |
| 3. Stator | 18. Anti-shock valve |
| 4. Rotor | 19. Roller bearing |
| 5. Screw | 20. Washer |
| 6. Spacer | 21. O-ring |
| 7. Screw | 22. Ring |
| 8. Seal | 23. Centring springs |
| 9. Closing plate | 24. O-ring |
| 10. O-ring | 25. "Orbitrol" distributor |
| 11. O-ring | 26. Pin |
| 12. Distributor plate | 27. Sleeve |
| 13. O-ring | 28. Anti-cavitation valve |
| 14. Connection shaft | 29. Safety valve |
| 15. Drum | |

**Operation - neutral position**

In this position, the drum (1) is centred with respect to the sleeve (2) by the springs.

Pipes P1-L-R are not supplied.


The oil from the pipe P passes directly to the pipe T to feed the hydraulic unit. The circuit is of the open centre type.

Two anti-shock valves (3) and two anti-cavitation valves (4) are placed in the holes L and R of the

distributor.

The anti-shock valves (3) protect the circuit between the steering cylinder and the distributor from shocks on the wheels.

The anti-cavitation valves (4) let the oil discharged from the anti-shock valves (3) to cross from the right pipe to the left pipe and vice versa, according to the shift of the piston in the steering cylinder.



- A. Steering cylinder
- B. Steering column position
- L. Feed to left union of steering cylinder
- P. Low flow rate feed from hydraulic pump


- P1. Feed to metering device
- R. Feed to right union of steering cylinder
- T. Discharge to hydraulic unit



Charge current and regulated voltage tests

Make sure that all the tractor's electrical users are off and that the ignition key is in the OFF position.

1. Disconnect negative battery terminal and terminal (1) of the alternator.
2. Connect an ammeter between the detached cable and alternator terminal (1).
3. Connect a voltmeter between terminal (1) of the alternator and ground.
4. Re-connect the battery. Start the engine and accelerate to 2000 RPM. Check the voltmeter and ammeter readings.



5



The voltmeter must give a higher value than the battery voltage and, when the ammeter reading drops below 10 A, the voltmeter reading must stabilize between 13.6 V 14 V.



5. Slowly increase the current charge (lowering the value of the resistance) until the ammeter reading becomes 40 A.
6. Check the voltmeter reading, which must not drop below 13.6 V.

A reading of less than 13.6 means that there is a defective component in the alternator. Test the alternator components as described in this chapter.

Alternator component tests

The component tests, which must only be carried out if the INITIAL TESTS have identified a defective component in the alternator, allow you to check:


- the governor;
- the no-break condition of the rotor field windings;
- the brushes, springs and contact rings of the rotor.




The previously described component tests can be conducted with the alternator installed in the tractor. To test the other components, the alternator must be removed from the tractor.



REAR PTO IGNITION, 4WD, BY SPEED SYSTEM, IGNITION SWITCH POWER RELAY CIRCUIT - Diagram A




4LA0052



External cab components


1. Opening front window
2. Front working lights
3. Clear top and sun-blinds
4. Rotating light
5. Adjustable rearview mirrors
6. Rear field lights
7. Opening rear window
8. Opening left and right side doors



2


Interior cab components

1. Front windscreen wiper
2. Front window locks



3

1. Cab air recirculation
2. Ventilation vents
3. Ceiling light
4. Rear window wiper



4