

"04

REPARATURANLEITUNG

REPAIR MANUAL

Edition 2004

MANUEL DE REPARATION

HUSABERG

6512146

HUSABERG
4 STROKE FORCE

PREFACE

This manual contains detailed instructions on repairing the engine. It was prepared according to the state of the art for this model series. We reserve the right to make modifications based on technical progress without making the respective corrections in this repair manual.

This manual does not contain a description of general shop or working methods. It does not include safety rules generally observed in workshops and is based on the assumption that the work is performed by a mechanic who has completed his vocational training.

Please read the entire manual before starting to work.



WARNING: failing to observe these instructions can be dangerous to life and limb.



CAUTION: failing to observe these instructions may damage the motorcycle/engine components or impair the motorcycle's traffic safety.



NOTE: provides useful information.

Only use **ORIGINAL HUSABERG SPARE PARTS** if parts need to be replaced.

The engine will only continue to operate safely if the prescribed service work is performed regularly and professionally.



Subject to changes in construction and design.

INDEX

GENERAL INFORMATION
DISMOUNTING AND MOUNTING THE ENGINE
DISASSEMBLING THE ENGINE
SERVICING THE INDIVIDUAL PARTS
ASSEMBLING THE ENGINE
ELECTRIC SYSTEM
FUEL SYSTEM
TROUBLESHOOTING
TECHNICAL SPECIFICATIONS
PERIODIC MAINTENANCE SCHEDULE
WIRING DIAGRAMS

A**B****C****D****E****F****G****H****I****J****K****L****M****N**

TABLE OF CONTENTS

GENERAL INFORMATION

Oil circuit	A1
Engine oil	A1
Checking the oil level	A1
Changing the engine oil	A2
Cleaning the oil screen	A2
Changing the oil filter	A3
Checking the oil level in the hydraulic clutch	A4
Bleeding the clutch	A4
Cleaning	A5
Preservation for winter operation	A5
Storage	A5
Special tools	A6

DISMOUNTING AND MOUNTING THE ENGINE

Dismounting the engine	B1
Mounting the engine	B5
Bleeding the cooling system	B9
Adjusting the decompression cable	B9
Adjusting the throttle cable	B9

DISASSEMBLING THE ENGINE

Blocking the engine	C1
Removing the rotor	C2
Removing the pressure relief valve	C2
Removing the clutch	C3
Removing inner clutch hub	C4
Removing primary pinion and the idler shaft gear	C4
Removing the oil pump	C5
Removing the chain tensioner	C6
Separating the timing chain	C6
Removing the cylinder head	C7
Separating the housing	C7
Removing the crankshaft	C8
Removing the transmission	C8
Removing the idler shaft	C9

SERVICING THE INDIVIDUAL PARTS

Important	D1
Left housing half	D1
Right housing half	D2
Pressure relief valve	D3
Clutch cover	D3
Crankshaft	D4
Press out the crank pin	D5
Press in the crank pin	D6
Checking the crankshaft journal	D7
Outer dimension of the crankshaft webs	D7
Balancing the axial clearance of the crankshaft	D8
Nikasil cylinder coating	D9
Measuring the piston and cylinder liner, determining the piston mounting clearance	D9
Checking the piston	D10
Checking the piston ring end gap	D10
Checking the oil pump for wear	D10
Cylinder head top section	D11
Cylinder head	D12
Camshaft	D14
Timing chain tensioner	D15
Timing train	D15
Checking the clutch for wear	D16
Checking the kickstarter for wear	D17
Shift mechanism	D18
Assembling the main shaft (four-speed)	D19
Assembling the main shaft (six-speed)	D20
Assembling the countershaft (four/six-speed)	D21
Starter drive	D22
Checking the freewheel	D22
Checking the freewheel hub	D22

ASSEMBLING THE ENGINE

Mounting the idler shaft	E1
Mounting the crankshaft	E2
Mounting the cylinder head	E4
Mounting the timing chain	E5

Mounting the timing chain tensioner	E7
Adjusting the valve clearance	E7
Mounting the oil pump	E8
Mounting the shift mechanism	E8
Mounting the kickstarter shaft	E9
Mounting the clutch	E9
Mounting the clutch cover	E11
Mounting the pressure relief valve	E13
Mounting rotor and pick up	E13

ELECTRIC SYSTEM

Checking for loss of current	F1
Dismounting/mounting the battery	F1
Charging the battery	F1
Filling the battery	F2
Checking the starter	F2
Checking the starter relay	F3
Checking the main fuse	F3
Checking the voltage regulator	F4
Kokusan 4K3B dynamic generator values	F4
Troubleshooting in the ignition system	F5
CDI unit	F6
Checking the ignition coil	F6
Ignition system	F7
Checking the stator and pulse generator	F7
Replacing the stator in FC models (Kokusan 4K-3A)	F7
Replacing the stator in FE and FS models (Kokusan 4K-3B)	F7
Static ignition values Kokusan 4K-3A/B	F8
Static generator values Kokusan 4K3B	F10

FUEL SYSTEM

KEIHIN FCR-MX 39/41	G1
Disassembling the carburetor	G2
Choke slide and hot start knob	G5
Accelerator pump	G5
Jet needle	G5
Float needle valve	G5
Throttle slide	G6
Assembling the carburetor	G6
Adjusting the throttle sensor position	G10
Checking the throttle sensor	G11
Dismounting and mounting the throttle sensor	G11
Adjusting the idle	G12
Checking/adjusting the float height	G13

TROUBLESHOOTING

Troubleshooting	H1
-----------------	----

TECHNICAL SPECIFICATIONS

Engine 450, 501	I1
Carburetor 450, 501	I1
Engine 550, 650	I2
Carburetor 550, 650	I2
Chassis	I3
Engine torques	I4
Chassis torques	I5
Mounting clearances, engine wear limits	I6

PERIODIC MAINTENANCE SCHEDULE

FC 450, 550/4	J1
FE 450 - 650e/6, FS 450, 650e/6	J2
Additional work - driver	J3
Additional work - workshop	J4


WIRING DIAGRAMS

FC models	K1
FE models	K2
FE USA models	K4
FS models	K6
Cable colors	K8

GENERAL INFORMATION

A
1

OIL CIRCUIT



DESCRIPTION:

The oil pump (1) draws the engine oil from the oil sump through the oil screen (2) and pumps it past the pressure relief valve (3) to the oil filter (4). It continues to the crankshaft (5), partly branching off through a hole to lubricate and cool the piston (6) and the piston pin bearing. Once through the crankshaft, the engine oil is pumped to the conrod bearing (7) and branches off again to the bearings in the balance weight (8).

The camshaft (9) is lubricated by the engine oil which is transported to the cylinder head by the timing chain (10). On the downward movement of the piston, engine oil is pressed from the crankcase through the diaphragm valve (not depicted) to the transmission and shift mechanism.

ENGINE OIL


Only use fully synthetic brand-name engine oils (e.g.: Motorex Power Synt. 4T) that meet or exceed the Jaso T903 MA quality requirements (information on the can).



CAUTION: not enough engine oil or low-quality oil will lead to premature engine wear.

JASO T903 MA

TEMPERATURE



CHECKING THE ENGINE OIL LEVEL



NOTE: the engine oil level can be checked when the engine is cold or warm.

- Place the motorcycle on a level surface (not on the side stand).

If the engine is cold, the engine oil should be visible at the lower edge (A) of the inspection glass.

If the engine is warm, the engine oil should reach the upper edge (B) of the inspection glass.

Add engine oil if necessary.



CAUTION: not enough engine oil or low-quality oil will lead to premature engine wear.

- Check the engine for leakage.

