

CONTENTS

	GENERAL INFORMATION	1
	FRAME/BODY PANELS/EXHAUST SYSTEM	2
	MAINTENANCE	3
ENGINE	LUBRICATION SYSTEM	4
	FUEL SYSTEM	5
	COOLING SYSTEM	6
	ENGINE REMOVAL/INSTALLATION	7
	CYLINDER HEAD/VALVE/CAMSHAFT	8
	CYLINDER/PISTON	9
	CENTRIFUGAL CLUTCH	10
	ALTERNATOR/STARTER CLUTCH	11
	SUB-TRANSMISSION/GEARSHIFT LINKAGE	12
	CRANKSHAFT/AUTOMATIC TRANSMISSION	13
CHASSIS	FRONT WHEEL/SUSPENSION/STEERING	14
	REAR WHEEL/SUSPENSION	15
	BRAKE SYSTEM	16
	FRONT DRIVING MECHANISM	17
	REAR DRIVING MECHANISM	18
ELECTRICAL	BATTERY/CHARGING SYSTEM	19
	IGNITION SYSTEM	20
	ELECTRIC STARTER	21
	LIGHTS/METERS/SWITCHES	22
	SELECTABLE 4WD SYSTEM	23
	HONDAMATIC	24
	WIRING DIAGRAMS	25
	TROUBLESHOOTING	26
	INDEX	27