




V-MAC[®] III


SERVICE MANUAL



OCTOBER 2008
(REVISED)
8-211



V-MAC[®] III SERVICE MANUAL



267422a

V-MAC III Diagnostic Equipment

OCTOBER 2008
(REVISED — SUPERSEDES ISSUE DATED JULY 2006)

© MACK TRUCKS, INC 2008
8-211



ATTENTION

The information in this manual is not all inclusive and cannot take into account all unique situations. Note that some illustrations are typical and may not reflect the exact arrangement of every component installed on a specific chassis.

The information, specifications, and illustrations in this publication are based on information that was current at the time of publication.

No part of this publication may be reproduced, stored in a retrieval system, or be transmitted in any form by any means including (but not limited to) electronic, mechanical, photocopying, recording, or otherwise without prior written permission of Mack Trucks, Inc.



TABLE OF CONTENTS

TABLE OF CONTENTS



TABLE OF CONTENTS

INTRODUCTION	1
SAFETY INFORMATION	2
Advisory Labels	2
Service Procedures and Tool Usage	3
Clean Air Act	4
ABOUT THIS MANUAL	4
DESCRIPTION AND OPERATION	5
V-MAC III SYSTEM OVERVIEW	6
Sensors	8
Cab and Dashboard Switches	12
V-MAC III MAJOR FUNCTIONS	18
TROUBLESHOOTING	21
SYSTEM DIAGNOSTICS	22
Diagnostic Tools	22
Electrical Terms	25
Troubleshooting Procedures	25
Reading Diagnostic Fault Codes	28
Fault Codes	33
SAE Message Descriptions	39
BLINK CODE 1-1 — ENGINE OIL PRESSURE (EOP) SENSOR (ASET™ IEGR ENGINE)	46
BLINK CODE 1-1 — ENGINE OIL PRESSURE (EOP) SENSOR (ASET™ CEGR ENGINE)	56
BLINK CODE 1-2 — BAROMETRIC PRESSURE SENSOR	66
BLINK CODE 1-3 — FUEL TEMPERATURE (FT) SENSOR (ASET™ IEGR ENGINE)	67
BLINK CODE 1-3 — FUEL TEMPERATURE (FT) SENSOR (ASET™ CEGR ENGINE)	76
BLINK CODE 1-4 — AMBIENT AIR TEMPERATURE (AAT) SENSOR (ASET™ IEGR ENGINE)	85
BLINK CODE 1-4 — AMBIENT AIR TEMPERATURE (AAT) SENSOR (ASET™ CEGR ENGINE)	93
BLINK CODE 1-6 — STARTER ENGAGED INPUT	101
BLINK CODE 1-7 — COOLANT LEVEL SENSOR (ASET™ IEGR ENGINE)	106
BLINK CODE 1-7 — COOLANT LEVEL SENSOR (ASET™ CEGR ENGINE)	112
BLINK CODE 1-8 — ESTIMATED % FAN SPEED (ASET™ IEGR ENGINE)	118
BLINK CODE 1-8 — ESTIMATED % FAN SPEED (ASET™ CEGR ENGINE)	125
BLINK CODE 1-10 — AUXILIARY COOLING RELAY OUTPUT	132
BLINK CODE 2-1 — ENGINE COOLANT TEMPERATURE (ECT) SENSOR (ASET™ IEGR ENGINE)	133
BLINK CODE 2-1 — ENGINE COOLANT TEMPERATURE (ECT) SENSOR (ASET™ CEGR ENGINE)	142
BLINK CODE 2-2 — BOOST AIR PRESSURE (BAP) SENSOR (ASET™ IEGR ENGINE)	151
BLINK CODE 2-2 — BOOST AIR PRESSURE (BAP) SENSOR (ASET™ CEGR ENGINE)	161
BLINK CODE 2-3 — INTAKE AIR TEMPERATURE (IAT) SENSOR (ASET™ IEGR ENGINE)	170
BLINK CODE 2-3 — INTAKE MANIFOLD TEMPERATURE (IMT) SENSOR (ASET™ CEGR ENGINE)	179
BLINK CODE 2-4 — TRANSMISSION OIL TEMPERATURE (TOT) SENSOR	189
BLINK CODE 2-5 — FRONT DRIVE AXLE OIL TEMPERATURE (FAOT) SENSOR	197