


Spare parts list Hydraulic breakers


Valid from serial number 50



Contents

General information.....	5
Spare parts list.....	6
Hydraulic breaker MB 750.....	6
Hydraulic breaker MB 750 DustProtector.....	8
Percussion unit part 1: cylinder cover.....	10
Percussion unit part 2: cylinder.....	12
Percussion unit part 3: lower breaker part.....	14
Connecting kit for ContiLube® II.....	16
Optional parts.....	18
Tightening torques.....	19
Working tools.....	20
MB 750.....	20
MB 750 DustProtector.....	21
Accessories.....	22
Hydraulic hoses.....	22
Optional equipment.....	22
Kits.....	23
Label kit MB 750.....	23
Label kit MB 750 DustProtector.....	24
Seal kit.....	25
Plastic parts kit.....	25
Tensioning bolt kit.....	25
DustProtector kit.....	26
Noise protection kit.....	26
Lower breaker part kit.....	26
Lower breaker part kit DustProtector.....	27
Dimensions.....	28
Dimensions MB 750.....	28
Dimensions MB 750 DustProtector.....	29

Percussion unit part 1: cylinder cover



No.	Description	Remark	Quantity	Part number
100	Cylinder cover		1	3363 0917 04
104	Seal		2	3363 0917 08
105	O-ring		2	3363 0917 09
106	Seal		1	3363 0917 10
107	O-ring		1	3360 3146 64
180(181-183)	Filling valve complete		1	3363 0872 86
181	Filling valve		1	-
182	Threaded plug		1	3360 4784 26
183	O-ring		1	3360 1751 25
191(192-193)	Tensioning bolt complete		4	3363 0917 02
192	Tensioning bolt		1	3363 0928 73
193	Washer		1	3363 0936 45