


TB007


Book No. PB4-101Z6
Serial No. 1073001-1074744



TAKEUCHI

Item	Part number	Description	INDEX				Remarks
			Q'ty	Chan.	Serial No.	Serv.	
1		UNDERCARRIAGE					
2		TURNTABLE & CONTROL LEVER					
3		ENGINE & ELECTRICAL SYSTEM					
4		HYDRAULIC PIPNG & TANK					
5		COVER & CAB					
6		HOE ATTACHMENT					
7		DECAL & TOOL					
8		HYDRAULIC DEVICE					
9		NUMERICAL INDEX					
10		ENGINE(2TN66L-UTBA)					
		ENGINE(2TNE68-ETB)					


TB007 Book No. PB4-101Z6 S/N1073001-1074744
SWIVEL JOINT



B4-45a-0-D

SWIVEL JOINT						
Item	Part number	Description	Q'ty	Chan.	Serial No.	Serv. Remarks
1	1904006800	JOINT, swivel ASSY	1			
2	1904006699	• KIT, seal	1			
3	1420010500	• • O-RING	8			
4	1421030500	• • RING, back-up	2			
5	1904006801	• HUB	1			
6	1904006811	• SHAFT	1			
7	1904006821	• FLANGE	1			
8	1904006604	• RING	1			
9	1904006608	• PIN	1			
10	1904006809	• COVER	1			
11	1904006610	• BRACKET	1			
12	1904006633	• BRACKET	1			
13	1904006612	• SPRING	1			
14	1420010090	• O-RING	9			
15	1420000080	• O-RING	1			
16	1420110600	• O-RING	2			
17	1420110350	• O-RING	1			
18	1420310033	• O-RING	1			
19	1220000045	• RING, snap	1			
20	1141200008	• WASHER	1			
21	1110050820	• SCREW, cap	4			
22	1110050695	• SCREW, cap	2			
23	1110050675	• SCREW, cap	4			
24	1110050625	• SCREW, cap	2			
25	1110050512	• SCREW, cap	4			
26	1501810002	• PLUG	2			
27	1501810000	• PLUG	1			
28	1904006632	• SELECTOR ASSY	1			
29	1904006653	• • COVER	1			
30	1904006654	• • COVER	1			
31	1904006655	• • SPRING	2			
32	1420010160	• • O-RING	2			
33	1420000100	• • O-RING	1			
34	1421020100	• • RING, back-up	1			
35	1390020350	• • BALL, steel	2			
36	1110050555	• • SCREW, cap	4			
37	1110050540	• • SCREW, cap	4			
38	1110050516	• • SCREW, cap	4			
39	1501810000	• • PLUG	2			
40	1411170080	• SEAL, dust	1			

B445a3L



Seal Kits								
Item	Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks	
		Seal Kits						
	1900056999	Seal Kit (bm) Multit Use - Swing Cylinder	1					
	1900056999	Seal Kit (bm) Multi Use - Blade Cylinder	1					
	1900056999	Seal Kit (bm) Multi Use - Bucket Cylinder	1					
	1900056999	Seal Kit (bm) Multi Use - Arm Cylinder	1					
	1900056999	Seal Kit (bm) Multi Use - Boom Cylinder	1					
	1900059699	Seal Kit (bm) Multit Use - Track Adjuster	1					

Page 10-16

This diagram illustrates the exploded view of a carburetor assembly, showing the relationship between various components. The parts are numbered as follows:

- Top Section (Air Filter/Housing):** Includes parts 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25.
- Carburetor Body:** Labeled as part 1, it features two main fuel passages labeled "No. 1" and "No. 2".
- Jet and Needle Assembly:** Includes parts 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50.
- Base Mounting:** Shows the carburetor being mounted onto a base (part 4) using screws (part 48) and a gasket (part 49).

Assembly instructions and references are provided:

- "REFER TO FIG. 12" is located near the bottom right of the main assembly.
- "REFER TO FIG. 4" is located near the base mounting section.
- Labels "No. 1" and "No. 2" identify the fuel passages.
- A circled "A" is used to denote specific assembly points or features.

FIG 11 FUEL INJECTION PUMP

Item	Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
1	Y719305-51100	PUMP ASSY. F.INJECT.	1				
2	Y119225-51100	PLUNGER W/BARREL	2				
3	Y119620-51170	RETAINER	2				
4	Y119620-51180	RETAINER	2				
5	Y119620-51190	SPRING, PLUNGER	2				
6	Y119620-51250	SHIM PACK	2				
7	Y119225-51300	VALVE W/SEAT, DELIV.	2				
8	Y105546-51330	SPRING, DELIV. VALVE	2				
9	Y119620-51340	HOLDER DELIV. VALVE	2				
10	Y119620-51350	GASKET, DELIVERY	2				
11	Y119620-51370	O-RING	2				
12	Y119620-51450	GUIDE, PLUNGER	2				
13	Y174307-51460	PIN	1				
14	Y119305-51500	RACK	1				
15	Y119620-51510	PINION	2				
16	Y119305-51530	RETAINER, RACK	1				
17	Y119620-51650	PLATE	1				
18	Y119620-51660	SCREW	1				
19	Y119620-51670	PIN	1				
20	Y119620-51680	PIN	1				
21	Y119620-51700	TAPPET ASSY	2				
22	Y22137-040000	WASHER 4, POLISHED	1				
23	Y22217-040000	SPRING WASHER 4	1				
24	Y26022-040082	SCREW M 4X 8	2				
25	Y26587-040102	SCREW M 4X 10	1				
26	Y719620-53700	VALVE ASSY, F.INJECT	2				
26-1	Y719620-23100	VALVE ASSY, F.INJECT	2				
27	Y119620-53000	NOZZLE ASSY, F.INJECT	2				
28	Y119620-53080	NUT, VALVE W/CASE	2				
29	Y119620-53100	HOLDER, VALVE W/CASE	2				
30	Y119620-53120	SPRING, VALVE	2				
31	Y114250-53130	SEAT, NOZZLE SPRING	2				
32	Y119620-53140	SPACER, VALVE STOP	2				
33	Y114250-53400	SHIM PACK	2				
34	Y129155-61830	O-RING S10	2				
34-1	Y129155-51580	O-RING	2				
35	Y119305-59120	RETAINER	1				
36	Y129150-59130	BOLT M 4X 12	1				
36-1	Y129150-59131	BOLT M 4X 12	1				
38	Y119305-59810	PIPE ASSY, FUEL	1				
39	Y119305-59820	PIPE ASSY, FUEL	1				
40	Y119332-59540	PIPE, FUEL RETURN	1				
41	Y124066-59100	CLAMP 8	2				
42	Y119260-59520	JOINT (B)	1				
43	Y119260-59530	JOINT (A)	1				
44	Y119260-59550	PIPE, FUEL	1				
45	Y119642-59550	PIPE, FUEL RETURN	1				
46	Y119642-59570	JOINT, OVER FLOW PIPE	1				
47	Y119620-59700	NUT	2				
48	Y124550-59820	BOLT 8, PIPE JOINT	1				
49	Y23414-080012	GASKET 8	2				
50	Y23414-140000	GASKET 14, ROUND	2				