




Nightshifter 4000

Parts Manual

Table of Contents

1.	Base Frame	1
2.	Axle Assembly	2
3.	Canopy	3
4.	Fuel Tank Assembly	5
5.	Ballast Box Assembly	6
6.	Battery Assembly	7
7.	Control Panel	8
8.	Engine/Alternator Assembly	9
9.	Exhaust Assembly	10
10.	Mast Post Assembly	11
11.	Ancillary Mast Components	12
12.	Mast Assembly	13
13.	Light Bar Assembly	15