

TABLE OF CONTENTS

MODEL/SERIAL NUMBER DESIGNATOR	iv
Section One	
INSTALLATION CONSIDERATIONS	1
GENERAL CONSIDERATIONS	1
S P E C I F I C A T I O N S.....	2
Section Two	
THEORY OF OPERATION	3
CONTROL PANEL	3
Model: GU1200XTK	
Cycle Selection Chart	3
Option Selection	5
Cycle Status Indicators	6
CONTROL PANEL	7
Model: GU1500XTK	
Cycle Selection Chart	7
FUNCTION DESCRIPTION	9
Section Three	
COMPONENT ACCESS	13
COMPONENT LOCATION	13
ACCESSING COMPONENTS IN THE DOOR	14
ACCESSING COMPONENTS INSIDE THE TUB	17
ACCESSING COMPONENTS OF THE PUMP ASSEMBLY	20
SERVICING THE DOOR HINGE.....	23
Section Four	
TROUBLESHOOTING AND DIAGNOSIS	25
TROUBLESHOOTING CHART	25
COMMON CYCLE TIME CHART	26
HOW TO USE COMMON CYCLE TME	28
COMMON CYCLE TIME CHART NOTES	31
DIAGNOSTIC CYCLE TIME CHART	35
RAPID ADVANCE FEATURE & DIAGNOSTIC CYCLES	36
Section Five	
TECH TIPS	37
WIRING DIAGRAM	37
MODEL SPECIFIC SERVICE PARTS TABLE	38
USER INTERFACE SWITCH MATRIX	38
STRIP CIRCUITS	39
ELECTRONIC CONTROL CONNECTOR PINS	40