


- 1. Air compressor
- 2. Injector harness
- 3. Electronic Control Module (ECM)
- 4. Engine 76-pin harness
- 5. Vehicle 76-pin harness
- 6. Valve cover (left)

- Glow plug harness assembly (left)
- 8. Exhaust manifold (left)
- 9. Fuel cooler assembly
- 10. Fuel cooler to filter tube assembly (secondary fuel filter)
- 11. Upper oil pan

- 12. Coolant-in hose (Coolant supply to fuel cooler)
- 13. Coolant-out from fuel cooler hose
- 14. Glow plug harness assembly connector (left)
- 15. Oil level gauge tube assembly

DOOR HALF OF HINGE

Adjust door forward or back at a sliding tapped mounting/adjustment plate (Item 3, <u>Figure 53</u>) inside the door through mounting bolt access holes (Item 2, <u>Figure 54</u>) in the door panel.



Electronic Engine Controls (Chassis Side)




Figure 70 Electronic Engine Controls (Chassis Mounted Components)