


## Removing the AirPort Extreme Card

1. Disconnect the two AirPort antennas and remove the two T6 screws.



922-7010



2. The board pops up when the screws are removed. Pull the AirPort Extreme card out of the slot in the direction of the arrow.

