


SHOP MANUAL

HONDA
CB 750



FOREWORD

This shop manual describes the maintenance, inspection and adjustment procedures for the HONDA CB750 and CB750F.

The manual is divided into various functional groups to simplify the use. The pages for the respective groups are indexed on this pages for convenience.

Each of the groups are further divided into section 1. Description, 2. Specifications, 3. Diagnosis, 4. Disassembly, 5. Inspection and 6. Reassembly. Photographs and illustrations make the operations easier to understand.

Following are the initial serial numbers of each model at the time of change.

CB750	Frame No. 1000001~
CB750K1	Frame No. 1055004~
CB750K2	Frame No. 2000001~
CB750K3	Frame No. 2200001~
CB750K4	Frame No. 2341915~
CB750K5	Frame No. 2525947~
CB750F	Frame No. 1000002~
CB750F1	Frame No. 2000003~
CB750K6	Frame No. 2540001~
CB750K7 ('77)	Frame No. 2700002~
CB750F ('77)	Frame No. 2100001~
CB750K ('78)	Frame No. 2800001~
CB750F ('78)	Frame No. 3100002~

HONDA MOTOR CO., LTD

Service Publications Office

GROUP INDEX

1. GENERAL INFORMATION. . .	1~15
2. ENGINE REMOVAL AND INSTALLATION.....	17~19
3. ENGINE MECHANICAL....	21~55
4. CLUTCH.....	57~61
5. TRANSMISSION.....	63~70
6. FUEL SYSTEM.....	71~82
7. IGNITION SYSTEM.....	83~92
8. CHARGING SYSTEM.....	93~102
9. STARTING SYSTEM.....	103~108
10. BATTERY.....	109~113
11. STEERING AND FRONT SUSPENSION.....	115~122
12. REAR SUSPENSION.....	123~128
13. WHEELS, TIRES AND FINAL DRIVE.....	129~139
14. BRAKES.....	141~149
15. BODY, OIL TANK, AIR CLEANER AND EXHAUST SYSTEM.....	151~156
16. BODY ELECTRICAL AND INSTRUMENTS....	157~170
17. WIRING DIAGRAM.....	171~172
18. ENGINE TUNE-UP.....	173~174
19. PERIODICAL MAINTENANCE.....	175~188
20. SUPPLEMENT TO CB750 K1~K4.....	189~220
21. SUPPLEMENT TO CB750 K5.....	221~224
22. SUPPLEMENT TO CB750 F.....	225~248
23. SUPPLEMENT TO CB750 K 6 ('76).....	249~252
24. SUPPLEMENT TO CB750 K 7 ('77).....	253~264
25. SUPPLEMENT TO CB750 F ('77).....	265~273
26. SUPPLEMENT TO CB750 K ('78).....	275~279
27. SUPPLEMENT TO CB750 F ('78).....	281~283

ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATEVER.

NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION.

GENERAL INFORMATION

GROUP

1

CONTENTS

1-1 SERIAL NUMBER	1
1-2 KEY SYSTEM	2
1-3 TECHNICAL DATA.....	3
a. Dimensional drawing	3
b. Specifications.....	4
c. Driving performance.....	10
1-4 THREAD SIZE	11
1-5 SERVICE TOOLS.....	12

1-1 SERIAL NUMBER




Fig. 1-1 ① Frame serial number




Fig. 1-2 ① Engine serial number

The frame serial number is stamped on the left side of the steering head pipe and engine serial number is located on the top of the crankcase left side. Whenever ordering replacement parts or making inquiries concerning the particular motorcycle, always included the frame or the engine number whichever is applicable. (Fig. 1-1, 2)